

Safety Instructions (Read these safety instructions before operating the unit.)

ENGLISH

WARNINGS

- Avoid high temperatures.
- Keep the unit free from moisture, water, and dust.
- Never disassemble or modify the unit in any way.
- **Naked flame sources such as lit candles should not be placed on the unit.**
- Do not connect the plug on the equipment for the connection between the connector and micro USB/USB cable.

DECLARATION OF CONFORMITY

Hereby, (D&M Holdings Inc.) declares that our product is in compliance with following E.U.C directives. The full text of the EU declaration of conformity is available at the following internet address:
RoHS: 2011/65/EU, and amendment Directive (EU) 2015/863

DECLARATION OF CONFORMITY (For UK customers)

Hereby, (D&M Holdings Inc.) declares that our product is in compliance with following UK regulations. The full text of the UKCA declaration of conformity is available at the following internet address:
<UKCA Regulations>

Das Verpackungsmaterial dieses Produktes ist zum Recyceln geeignet und kann wieder verwendet werden. Bitte entsorgen Sie alle Materialien entsprechend der örtlichen Recycling-Vorschriften.

This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with the local recycling regulations. When discarding the unit, comply with local rules or regulations. Batteries should never be thrown away or incinerated but disposed of in accordance with the local regulations concerning disposal. This product and its supplies contain potentially hazardous substances that are generally associated with waste electrical and electronic equipment.

Safety notices

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Wenn Ihr Gehör längere Zeit übermäßig Schallebene ausgesetzt wird, kann dies zu einer irreversiblen Gehörsehvermögen (LSH) führen.

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Over exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please use the following guidelines established by the occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

- Do not use any accessories, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not place heavy objects on, or pull on the headphones. Doing so may damage or deform the headphones.
- Store the ear pieces out of the reach of children to prevent small children from accidentally swallowing them.
- Do not remove any covers, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not bend forcibly the plug on the equipment for the connection between the connector and micro USB/USB cable.

Caution on handling

- Be sure to hold the plug when unplugging the cable.
- **Do not place undue stress on the cable, as this can result in wire disconnection or damage.**
- Do not touch the cable directly.
- Do not allow a portable device to hang from the headphones.
- Do not wrap the cable around the portable device.
- If you allow a portable device to hang from the headphones, it may become unstable and fall. DENON does not warrant the performance and shorten the life of the internal rechargeable battery.
- Metal parts will come in contact with your skin. People with allergies to metal should not use these headphones. If you feel that the headphones irritate your skin during use, stop using them and contact a physician for advice.
- Do not use benzene, thinners, or other organic solvents or insecticides on the main unit since they may cause a change in quality or color.
- Do not follow a hot headpiece when the volume is too high, which may annoy people around you. Please be considerate and lower the volume.

Rechargeable battery precautions

- There is a possibility of smoke, fire, explosion from the rechargeable battery, and battery overheating. Do not touch the battery when it is hot.
- Do not touch the rechargeable battery into a fire, and do not heat up the battery. Doing so could cause battery heat generation, battery fires, and battery rupture.
- Do not use the rechargeable battery for anything other than charging, or stepping it with sharp objects like nail, etc., tapping it with a hammer, or stopping it in. Doing so could cause battery heat generation, battery fires, and battery rupture.
- Do not place foreign objects inside this unit. Doing so could cause fires and electrical shocks.
- Do not use this unit in a microwave oven or in a high-pressure container.
- Do not place this unit on top of an electromagnetic cooker.
- Do not attempt to recharge the internal rechargeable battery by connecting it to a power outlet or a car's cigarette lighter.
- Strictly observe the recharging procedure and conditions specified by DENON.
- If fluid should leak from the rechargeable battery and get into the eyes, do not rub the eyes. Instead, rub the eyes thoroughly with tap water, etc., and see a doctor without delay for treatment. Leaving the eyes untreated could result in serious eye damage.
- Do not use near medical devices, automatic doors, or fire alarms, etc. Signals from this unit could interfere with the operation of those devices, possibly causing malfunctions and accidents.
- If recharging takes longer than the prescribed recharging time period has elapsed, stop the recharging operation. Continuing to recharge the battery could cause battery heat generation, battery fires, and battery rupture.

Vorsichtsmaßnahmen für die wiederaufladbare Batterie

- Es kann beim Akku zur Rauchentwicklung, einem Brand oder einer Explosion kommen. Bitte beachten Sie Folgendes:
 - Die wiederaufladbare Batterie nicht mit Feuer werfen und nicht erhitzen. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
 - Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
 - Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
- Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
- Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
- Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.

Precautions for use

- Remove and immediately recycle or dispose of used batteries according to local laws and regulations. Do NOT dispose of batteries in household trash or incinerate.
- Used batteries may cause severe injury or death.
- Call a physician immediately if you experience any of the following symptoms:
 - Insert the specified batteries in the earbuds (Lithium-ion rechargeable battery 1454, DCR 3 V).
 - Do not discharge, recharge, disassemble, heat above 95 °F (35 °C) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
 - This product contains non-replaceable button cell batteries.

WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **10 hours**.
- **KEEP** new and used batteries **OUT OF REACH** of children.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

DEUTSCH

WARNHINWEISE

- Vermeiden Sie hohe Temperaturen.
- Halten Sie das Gerät von Feuchtigkeit, Wasser und Staub fern.
- Versuchen Sie niemals das Gerät auseinander zu nehmen oder zu verändern.
- **Nie** am Gerät solche keinerlei direkt Feuerquellen wie brennende Kerzen oder Kerzen aufstellen.
- **Nie** am Gerät das Feuerzeug oder die Zigarettenanzünder des Anschließers und Micro-USB/USB-Kabeln nicht mit Gewalt gebogen werden.

ÜBEREINSTIMMUNGSERKLÄRUNG

Hiemert erklärt (D&M Holdings Inc.), dass unser Produkt der, dass die folgenden EU-CE-Richtlinien entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar:
RoHS: 2011/65/EU und Änderungsrichtlinie (EU) 2015/863

Hiemert erklärt (D&M Holdings Inc.), dass unser Produkt der, dass die folgenden EU-CE-Richtlinien entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: RoHS: 2011/65/EU und Änderungsrichtlinie (EU) 2015/863

Hiemert erklärt (D&M Holdings Inc.), dass unser Produkt der, dass die folgenden EU-CE-Richtlinien entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: RoHS: 2011/65/EU und Änderungsrichtlinie (EU) 2015/863

Das Verpackungsmaterial dieses Produktes ist zum Recyceln geeignet und kann wieder verwendet werden. Bitte entsorgen Sie alle Materialien entsprechend der örtlichen Recycling-Vorschriften.

This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with the local recycling regulations. When discarding the unit, comply with local rules or regulations. Batteries should never be thrown away or incinerated but disposed of in accordance with the local regulations concerning disposal. This product and its supplies contain potentially hazardous substances that are generally associated with waste electrical and electronic equipment.

Sicherheitshinweise

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Wenn Ihr Gehör längere Zeit übermäßig Schallebene ausgesetzt wird, kann dies zu einer irreversiblen Gehörsehvermögen (LSH) führen.

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Over exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please use the following guidelines established by the occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

- Do not use any accessories, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not place heavy objects on, or pull on the headphones. Doing so may damage or deform the headphones.
- Store the ear pieces out of the reach of children to prevent small children from accidentally swallowing them.
- Do not remove any covers, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not bend forcibly the plug on the equipment for the connection between the connector and micro USB/USB cable.

Caution on handling

- Be sure to hold the plug when unplugging the cable.
- **Do not place undue stress on the cable, as this can result in wire disconnection or damage.**
- Do not touch the cable directly.
- Do not allow a portable device to hang from the headphones.
- Do not wrap the cable around the portable device.
- If you allow a portable device to hang from the headphones, it may become unstable and fall. DENON does not warrant the performance and shorten the life of the internal rechargeable battery.
- Metal parts will come in contact with your skin. People with allergies to metal should not use these headphones. If you feel that the headphones irritate your skin during use, stop using them and contact a physician for advice.
- Do not use benzene, thinners, or other organic solvents or insecticides on the main unit since they may cause a change in quality or color.
- Do not follow a hot headpiece when the volume is too high, which may annoy people around you. Please be considerate and lower the volume.

Rechargeable battery precautions

- There is a possibility of smoke, fire, explosion from the rechargeable battery, and battery overheating. Do not touch the battery when it is hot.
- Do not touch the rechargeable battery into a fire, and do not heat up the battery. Doing so could cause battery heat generation, battery fires, and battery rupture.
- Do not use the rechargeable battery for anything other than charging, or stepping it with sharp objects like nail, etc., tapping it with a hammer, or stopping it in. Doing so could cause battery heat generation, battery fires, and battery rupture.
- Do not place foreign objects inside this unit. Doing so could cause fires and electrical shocks.
- Do not use this unit in a microwave oven or in a high-pressure container.
- Do not place this unit on top of an electromagnetic cooker.
- Do not attempt to recharge the internal rechargeable battery by connecting it to a power outlet or a car's cigarette lighter.
- Strictly observe the recharging procedure and conditions specified by DENON.
- If fluid should leak from the rechargeable battery and get into the eyes, do not rub the eyes. Instead, rub the eyes thoroughly with tap water, etc., and see a doctor without delay for treatment. Leaving the eyes untreated could result in serious eye damage.
- Do not use near medical devices, automatic doors, or fire alarms, etc. Signals from this unit could interfere with the operation of those devices, possibly causing malfunctions and accidents.
- If recharging takes longer than the prescribed recharging time period has elapsed, stop the recharging operation. Continuing to recharge the battery could cause battery heat generation, battery fires, and battery rupture.

Vorsichtsmaßnahmen für die wiederaufladbare Batterie

- Es kann beim Akku zur Rauchentwicklung, einem Brand oder einer Explosion kommen. Bitte beachten Sie Folgendes:
 - Die wiederaufladbare Batterie nicht mit Feuer werfen und nicht erhitzen. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
 - Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
 - Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
- Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
- Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.

Precautions for use

- Remove and immediately recycle or dispose of used batteries according to local laws and regulations. Do NOT dispose of batteries in household trash or incinerate.
- Used batteries may cause severe injury or death.
- Call a physician immediately if you experience any of the following symptoms:
 - Insert the specified batteries in the earbuds (Lithium-ion rechargeable battery 1454, DCR 3 V).
 - Do not discharge, recharge, disassemble, heat above 95 °F (35 °C) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
 - This product contains non-replaceable button cell batteries.

FRANCAIS

AVERTISSEMENTS

- Éviter des températures élevées.
- Tenir l'appareil loin de l'humidité, l'eau et la poussière.
- **Né** jamais démonter ou modifier l'appareil d'une manière ou d'une autre.
- **Né** jamais placer de flamme nue sur l'appareil, notamment des bougies allumées.
- **Né** jamais plaquer la fiche sur l'appareil en forçant pour connecter la borne au câble micro USB/USB.

DECLARATION DE CONFORMITE

Hiemert déclare (D&M Holdings Inc.), que notre produit est en conformité avec les directives UE/CE. Le texte complet de la déclaration UE/CE de conformité est disponible à l'adresse internet suivante:
RoHS: 2011/65/UE et Directive déléguée (UE) 2015/863

Hiemert déclare (D&M Holdings Inc.), que notre produit est en conformité avec les directives UE/CE. Le texte complet de la déclaration UE/CE de conformité est disponible à l'adresse internet suivante: RoHS: 2011/65/UE et Directive déléguée (UE) 2015/863

Hiemert déclare (D&M Holdings Inc.), que notre produit est en conformité avec les directives UE/CE. Le texte complet de la déclaration UE/CE de conformité est disponible à l'adresse internet suivante: RoHS: 2011/65/UE et Directive déléguée (UE) 2015/863

Das Verpackungsmaterial dieses Produktes ist zum Recyceln geeignet und kann wieder verwendet werden. Bitte entsorgen Sie alle Materialien entsprechend der örtlichen Recycling-Vorschriften.

This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with the local recycling regulations. When discarding the unit, comply with local rules or regulations. Batteries should never be thrown away or incinerated but disposed of in accordance with the local regulations concerning disposal. This product and its supplies contain potentially hazardous substances that are generally associated with waste electrical and electronic equipment.

Sicherheitshinweise

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Wenn Ihr Gehör längere Zeit übermäßig Schallebene ausgesetzt wird, kann dies zu einer irreversiblen Gehörsehvermögen (LSH) führen.

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Over exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please use the following guidelines established by the occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

- Do not use any accessories, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not place heavy objects on, or pull on the headphones. Doing so may damage or deform the headphones.
- Store the ear pieces out of the reach of children to prevent small children from accidentally swallowing them.
- Do not remove any covers, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not bend forcibly the plug on the equipment for the connection between the connector and micro USB/USB cable.

Caution on handling

- Be sure to hold the plug when unplugging the cable.
- **Do not place undue stress on the cable, as this can result in wire disconnection or damage.**
- Do not touch the cable directly.
- Do not allow a portable device to hang from the headphones.
- Do not wrap the cable around the portable device.
- If you allow a portable device to hang from the headphones, it may become unstable and fall. DENON does not warrant the performance and shorten the life of the internal rechargeable battery.
- Metal parts will come in contact with your skin. People with allergies to metal should not use these headphones. If you feel that the headphones irritate your skin during use, stop using them and contact a physician for advice.
- Do not use benzene, thinners, or other organic solvents or insecticides on the main unit since they may cause a change in quality or color.
- Do not follow a hot headpiece when the volume is too high, which may annoy people around you. Please be considerate and lower the volume.

Rechargeable battery precautions

- There is a possibility of smoke, fire, explosion from the rechargeable battery, and battery overheating. Do not touch the battery when it is hot.
- Do not touch the rechargeable battery into a fire, and do not heat up the battery. Doing so could cause battery heat generation, battery fires, and battery rupture.
- Do not use the rechargeable battery for anything other than charging, or stepping it with sharp objects like nail, etc., tapping it with a hammer, or stopping it in. Doing so could cause battery heat generation, battery fires, and battery rupture.
- Do not place foreign objects inside this unit. Doing so could cause fires and electrical shocks.
- Do not use this unit in a microwave oven or in a high-pressure container.
- Do not place this unit on top of an electromagnetic cooker.
- Do not attempt to recharge the internal rechargeable battery by connecting it to a power outlet or a car's cigarette lighter.
- Strictly observe the recharging procedure and conditions specified by DENON.
- If fluid should leak from the rechargeable battery and get into the eyes, do not rub the eyes. Instead, rub the eyes thoroughly with tap water, etc., and see a doctor without delay for treatment. Leaving the eyes untreated could result in serious eye damage.
- Do not use near medical devices, automatic doors, or fire alarms, etc. Signals from this unit could interfere with the operation of those devices, possibly causing malfunctions and accidents.
- If recharging takes longer than the prescribed recharging time period has elapsed, stop the recharging operation. Continuing to recharge the battery could cause battery heat generation, battery fires, and battery rupture.

Vorsichtsmaßnahmen für die wiederaufladbare Batterie

- Es kann beim Akku zur Rauchentwicklung, einem Brand oder einer Explosion kommen. Bitte beachten Sie Folgendes:
 - Die wiederaufladbare Batterie nicht mit Feuer werfen und nicht erhitzen. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
 - Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
 - Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
- Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
- Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.

Precautions for use

- Remove and immediately recycle or dispose of used batteries according to local laws and regulations. Do NOT dispose of batteries in household trash or incinerate.
- Used batteries may cause severe injury or death.
- Call a physician immediately if you experience any of the following symptoms:
 - Insert the specified batteries in the earbuds (Lithium-ion rechargeable battery 1454, DCR 3 V).
 - Do not discharge, recharge, disassemble, heat above 95 °F (35 °C) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
 - This product contains non-replaceable button cell batteries.

ITALIANO

AVVERTENZE

- Evitare di esporre l'unità a temperature elevate.
- Tenere l'unità lontana da umidità, acqua e dalla polvere.
- Non smontare né modificare l'unità in alcun modo.
- **Né** mai posizionare sull'unità fiamme libere, come ad esempio candele accese, ceri, sigarette, ecc.
- **Né** mai pungere con forza lo spinotto sull'apparecchio per collegarlo al cavo micro USB/USB.

DECLARAZIONE DI CONFORMITÀ

Il fabbricante, (D&M Holdings Inc.), dichiara che il nostro prodotto è conforme alle direttive UE/CE. Il testo completo della dichiarazione UE/CE di conformità è disponibile al seguente indirizzo Internet:
RoHS: 2011/65/UE e Direttiva delegata (UE) 2015/863

Il fabbricante, (D&M Holdings Inc.), dichiara che il nostro prodotto è conforme alle direttive UE/CE. Il testo completo della dichiarazione UE/CE di conformità è disponibile al seguente indirizzo Internet: RoHS: 2011/65/UE e Direttiva delegata (UE) 2015/863

Il fabbricante, (D&M Holdings Inc.), dichiara che il nostro prodotto è conforme alle direttive UE/CE. Il testo completo della dichiarazione UE/CE di conformità è disponibile al seguente indirizzo Internet: RoHS: 2011/65/UE e Direttiva delegata (UE) 2015/863

Das Verpackungsmaterial dieses Produktes ist zum Recyceln geeignet und kann wieder verwendet werden. Bitte entsorgen Sie alle Materialien entsprechend der örtlichen Recycling-Vorschriften.

This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with the local recycling regulations. When discarding the unit, comply with local rules or regulations. Batteries should never be thrown away or incinerated but disposed of in accordance with the local regulations concerning disposal. This product and its supplies contain potentially hazardous substances that are generally associated with waste electrical and electronic equipment.

Sicherheitshinweise

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Wenn Ihr Gehör längere Zeit übermäßig Schallebene ausgesetzt wird, kann dies zu einer irreversiblen Gehörsehvermögen (LSH) führen.

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Over exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please use the following guidelines established by the occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

- Do not use any accessories, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not place heavy objects on, or pull on the headphones. Doing so may damage or deform the headphones.
- Store the ear pieces out of the reach of children to prevent small children from accidentally swallowing them.
- Do not remove any covers, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not bend forcibly the plug on the equipment for the connection between the connector and micro USB/USB cable.

Caution on handling

- Be sure to hold the plug when unplugging the cable.
- **Do not place undue stress on the cable, as this can result in wire disconnection or damage.**
- Do not touch the cable directly.
- Do not allow a portable device to hang from the headphones.
- Do not wrap the cable around the portable device.
- If you allow a portable device to hang from the headphones, it may become unstable and fall. DENON does not warrant the performance and shorten the life of the internal rechargeable battery.
- Metal parts will come in contact with your skin. People with allergies to metal should not use these headphones. If you feel that the headphones irritate your skin during use, stop using them and contact a physician for advice.
- Do not use benzene, thinners, or other organic solvents or insecticides on the main unit since they may cause a change in quality or color.
- Do not follow a hot headpiece when the volume is too high, which may annoy people around you. Please be considerate and lower the volume.

Rechargeable battery precautions

- There is a possibility of smoke, fire, explosion from the rechargeable battery, and battery overheating. Do not touch the battery when it is hot.
- Do not touch the rechargeable battery into a fire, and do not heat up the battery. Doing so could cause battery heat generation, battery fires, and battery rupture.
- Do not use the rechargeable battery for anything other than charging, or stepping it with sharp objects like nail, etc., tapping it with a hammer, or stopping it in. Doing so could cause battery heat generation, battery fires, and battery rupture.
- Do not place foreign objects inside this unit. Doing so could cause fires and electrical shocks.
- Do not use this unit in a microwave oven or in a high-pressure container.
- Do not place this unit on top of an electromagnetic cooker.
- Do not attempt to recharge the internal rechargeable battery by connecting it to a power outlet or a car's cigarette lighter.
- Strictly observe the recharging procedure and conditions specified by DENON.
- If fluid should leak from the rechargeable battery and get into the eyes, do not rub the eyes. Instead, rub the eyes thoroughly with tap water, etc., and see a doctor without delay for treatment. Leaving the eyes untreated could result in serious eye damage.
- Do not use near medical devices, automatic doors, or fire alarms, etc. Signals from this unit could interfere with the operation of those devices, possibly causing malfunctions and accidents.
- If recharging takes longer than the prescribed recharging time period has elapsed, stop the recharging operation. Continuing to recharge the battery could cause battery heat generation, battery fires, and battery rupture.

Vorsichtsmaßnahmen für die wiederaufladbare Batterie

- Es kann beim Akku zur Rauchentwicklung, einem Brand oder einer Explosion kommen. Bitte beachten Sie Folgendes:
 - Die wiederaufladbare Batterie nicht mit Feuer werfen und nicht erhitzen. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
 - Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
 - Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
- Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.
- Die wiederaufladbare Batterie nicht übermäßig Kraftentwicklung aussetzen, z. B. nicht mit scharfkantigen Gegenständen (einem Nagel usw.) darauf einwirken, nicht mit einem Hammer schlagen und nicht darauf treten. Dies könnte zu Wärmeentwicklung in der Batterie, zu Batteriebränden und zum Reißren der Batterie führen.

Precautions for use

- Remove and immediately recycle or dispose of used batteries according to local laws and regulations. Do NOT dispose of batteries in household trash or incinerate.
- Used batteries may cause severe injury or death.
- Call a physician immediately if you experience any of the following symptoms:
 - Insert the specified batteries in the earbuds (Lithium-ion rechargeable battery 1454, DCR 3 V).
 - Do not discharge, recharge, disassemble, heat above 95 °F (35 °C) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
 - This product contains non-replaceable button cell batteries.

ESPAÑOL

ADVERTENCIAS

- Evitar las temperaturas elevadas.
- Mantener el equipo lejos de la humedad, agua y polvo.
- No desmontar ni modificar el equipo en ninguna manera.
- **Né** nunca colocar sobre el aparato fuentes inflamables como velas encendidas, cerillos o cigarrillos encendidos.
- **Né** no doblar a la fuerza la clavija del equipo para la conexión entre el conector y el cable micro USB/USB.

DECLARACIÓN DE CONFORMIDAD

El fabricante, (D&M Holdings Inc.), declara que el nuestro producto es conforme con la Directiva UE/CE. El texto completo de la declaración UE/CE de conformidad está disponible en la dirección Internet siguiente:
RoHS: 2011/65/UE y Directiva con enmienda (UE) 2015/863

El fabricante, (D&M Holdings Inc.), declara que el nuestro producto es conforme con la Directiva UE/CE. El texto completo de la declaración UE/CE de conformidad está disponible en la dirección Internet siguiente: RoHS: 2011/65/UE y Directiva con enmienda (UE) 2015/863

El fabricante, (D&M Holdings Inc.), declara que el nuestro producto es conforme con la Directiva UE/CE. El texto completo de la declaración UE/CE de conformidad está disponible en la dirección Internet siguiente: RoHS: 2011/65/UE y Directiva con enmienda (UE) 2015/863

Das Verpackungsmaterial dieses Produktes ist zum Recyceln geeignet und kann wieder verwendet werden. Bitte entsorgen Sie alle Materialien entsprechend der örtlichen Recycling-Vorschriften.

This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with the local recycling regulations. When discarding the unit, comply with local rules or regulations. Batteries should never be thrown away or incinerated but disposed of in accordance with the local regulations concerning disposal. This product and its supplies contain potentially hazardous substances that are generally associated with waste electrical and electronic equipment.

Sicherheitshinweise

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Wenn Ihr Gehör längere Zeit übermäßig Schallebene ausgesetzt wird, kann dies zu einer irreversiblen Gehörsehvermögen (LSH) führen.

The maximum sound pressure level of this headphone is 100 dB. Please be careful to the volume level when using for a long time. Over exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please use the following guidelines established by the occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

- Do not use any accessories, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not place heavy objects on, or pull on the headphones. Doing so may damage or deform the headphones.
- Store the ear pieces out of the reach of children to prevent small children from accidentally swallowing them.
- Do not remove any covers, disassemble, or revert the headphones. Ask your place of purchase for internal checkups, adjustments, and repairs of the headphones.
- Do not bend forcibly the plug on the equipment for the connection between the connector and micro USB/USB cable.

Caution on handling

