

# Remote Control Preset Codes (AVC-A110)

## AVR

**D** Denon 73347

## CBL/SAT group

### CBL

**A** ABN 03322  
 ADB 01927, 02254  
 Alcatel-Lucent 02901  
 Amino 01602, 01481, 01822, 02482  
 Arion 03034, 03336  
 Arris 02187  
 AT&T 00858  
 au 03444, 03445, 03485, 03534  
**B** BBTv 02516, 02518, 02980  
 Bell 01998  
 BIG.BOX 03465  
 Bright House 01376, 01877  
 BSI 02979  
 BT 02294  
**C** C&M 02962, 02979, 03319, 03407  
 Cable Magico 03035  
 Cable One 01376, 01877  
 Cable&Wireless 01068  
 Cablecom 01582  
 Cablevision 01376, 01877, 03336

CCS 03322  
 Celrun 02959, 03196, 03442  
 Channel Master 03118  
 Charter 01376, 01877, 02187  
 Chunghwa 01917  
 Cisco 01877, 00858, 01982, 02345, 02378, 02563, 03028, 03265, 03294  
 CJ 03322  
 CJ Digital 02693, 02979  
 CJ HelloVision 03322  
 ClubInternet 02132  
 CMB 02979, 03389  
 CMBTV 03498  
 CNS 02350, 02980  
 Com Hem 00660, 01666, 02015, 02832  
 Comcast 01376, 00476, 01877, 01982, 02187  
 Coship 03318  
 Cox 01376, 01877  
**D** Daeryung 01877  
 DASAN 02683  
 Digeo 02187

Director 00476  
 DMT 03036  
 DSD 03340  
 DST 03389  
 DV 02979  
**E** Echostar 03452  
 Entone 02302  
**F** Freebox 01976  
**G** GBN 03407  
 GCS 03322  
 GDCATV 02980  
 Gehua 00476  
 General Instrument 00476  
**H** Hana TV 02681, 02881, 02959  
 Handan 03524  
 HCN 02979, 03340  
 HDT 02959, 03465  
 Hello TV 03322  
 HelloD 02979  
 Hi-DTV 03500  
 Hikari TV 03237

AVR		CBL/SAT group		TV group		VCR/PVR group		BD/DVD group		Audio group	
Homecast	02977, 02979, 03389	<b>L</b>	LG	02692, 02979, 03196, 03340, 03389, 03406, 03407, 03500	Panasonic	01982, 02703, 02752, 03474, 03475					
Huawei	01991		LG U+	02682, 03196		Philips	01582, 02174, 02294				
Humax	00660, 01981, 01983, 02165, 02620, 02683, 02701, 02832, 02881, 02962, 03051, 03053	<b>M</b>	Mediacom	01376, 01877	Pioneer	01877, 02700					
HYA	02989		Mega	02683	Pirelli	02944					
Hyroad	02979	Mega TV	02683	Premiere	02620						
<b>I</b>	I-Digital	03319, 03499	Minerva Networks	03118	Prime	03033					
	i3 Micro	01602	MIO	02275, 02802	PX	03348					
	Insight	01376, 01877	mio TV	02275, 02802	<b>Q</b>	Qook TV	02683				
ITV	02979, 03389	Mitsubishi	03274, 03444, 03485	Qrix		02979, 03465					
<b>J</b>	J:COM	02700, 02701, 02703, 02752, 03051, 03053	Motorola	01376, 00476, 00858, 01562, 01982, 01998, 02275, 02378, 03445, 03534	<b>R</b>	Qtel	01822				
	JCN	03491	MovieLink	03276		RCN	01376, 00476				
	Jerrold	00476	Moxi	02187	Rogers	01877					
	Jiuzhou	01991	MTS	01998	<b>S</b>	Sagem	02407				
<b>K</b>	Kabel Deutschland	01981, 01983	MyLGTV	02682		Samsung	01877, 01060, 01666, 01987, 02015, 02174, 02407, 02610, 02683, 02962, 02979, 03319, 03322, 03340, 03407, 03491				
	KabelBW	01981, 01983, 02174	Myrio	01602, 01822	Sasktel	01998					
Kaon	02979, 03389, 03407	<b>N</b>	Neuf TV	03107	SBC	03406					
kbro	02350		NIB	03322	Scientific Atlanta	01877, 00858, 01982, 01987, 02132, 02345, 03028					
KCN	02979, 03389	Now TV	02014	SCS	03500						
KCTV	02979, 03340	NTL	01068, 01060	SCV	02950						
KCTV JEJU	02979, 03356	NTT	03237, 03274	Sejin	01602						
KCTV-KJ	03500	Nuevo Siglo	03524	Seokyoung	03340						
KDDI	03444, 03445, 03485, 03534	<b>O</b>	Oi TV	03452, 03454	SetaBox	01917					
KDMC	02979		OllehTV	02683, 03478	SFR	03107					
Kiryung	03498	Ono	01068, 01562	Sharp	03349						
Kiss	02132	Optus	01060	Shaw	01376, 02187						
Knology	01877	Orange	02407	SingTel	01998, 02275, 02802						
KoolConnect	01481	<b>P</b>	Pace	01376, 01877, 01068, 01060, 01982, 02620, 03454	SK Broadband	02959, 03442					
KT	02683, 03478										

AVR		CBL/SAT group		TV group		VCR/PVR group		BD/DVD group		Audio group	
<b>T</b>	SK BTV	03442			True Visions	03075			Cablevision	01376, 01877, 03336	
	SKBtv	02681, 02881, 02959		<b>U</b>	U+	03196			CCS	03322	
	SKY	02620			Unihan	02453			Celrun	03442	
	SKY Deutschland	02174, 02620			Unitymedia	02610			Charter	01376, 01877, 02187	
	SkyCable	02893, 02950, 03241, 03318, 03521		<b>V</b>	UPC	01582			Cisco	01877, 01982, 03265	
	Skyworth	01991, 02893, 03521			VeeTV	03231			CJ HelloVision	03322	
	SMtronics	03319			Verizon	02378			Com Hem	02832	
	StarHub	01927			Vidéotron	01877			Comcast	01376, 01877, 01982, 02187	
	Stofa	02015			Virgin Media	01068, 01060, 01987, 02563, 03265			Cox	01376, 01877	
	Suddenlink	01376, 01877		<b>W</b>	VTR	01376			<b>D</b>	Digeo	02187
	SureWest	01481, 01998			Welho	02832			<b>F</b>	Freebox	01976
	Suwon Cable	03319			WideOpenWest	01877			<b>G</b>	GCS	03322
	T-Home	02132			WNC	03118			<b>H</b>	Hana TV	02959
	Tbroad	03319		<b>Y</b>	YBN	03322				Handan	03524
	TCN	03340			Yuxing	02014				Hello TV	03322
	Technotrend	03035		<b>Z</b>	Zhong Hua Dian Xin	01917				Humax	01981, 01983, 02165, 02620, 02832, 02962, 03051, 03053
	Telefonica	02901, 02944, 03028, 03033, 03034, 03035, 03036			Ziggo	00660, 01666, 02015			<b>I</b>	I-Digital	03499
	Telenet	01920			ZyXEL	02944				Insight	01376, 01877
	Telewest	01068, 01987		<b>CBL/PVR Combination</b>							
	Telus	02345		<b>A</b>	Amino	01822			<b>J</b>	J:COM	02700, 02703, 03051, 03053
TFN	03127, 03139			Arion	03336			<b>K</b>	kbro	02350	
Thomson	01582, 01981, 01982, 01983, 02174, 02407			Arris	02187				KDDI	03444	
Time Warner	01376, 01877, 02187			au	03444				Knology	01877	
ToongTV	03322		<b>B</b>	BBTV	02980			<b>M</b>	Mediacom	01376, 01877	
Topfield	02981			Bright House	01376, 01877				Mitsubishi	03444	
TopTV	01991			C&M	02962, 03407				Motorola	01376	
Topway	01991		<b>C</b>	Cable One	01376, 01877				Moxi	02187	
TP	02407			Cablecom	01582				Myrio	01822	
								<b>N</b>	Nuevo Siglo	03524	
								<b>P</b>	Pace	01877, 02620	
									Panasonic	01982, 02703	

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

<b>R</b>	Philips	01582
<b>S</b>	Pioneer	01877, 02700
	Rogers	01877
	Samsung	01877, 01987, 03407
	Scientific Atlanta	01877, 01982, 01987
	Shaw	01376, 02187
	SK Broadband	03442
	SK BTV	03442
	SKY	02620
	SKY Deutschland	02620
	SkyCable	03241, 03521
	Skyworth	03521
	StarHub	01927
	Suddenlink	01376, 01877
<b>T</b>	Telenet	01920
	Telewest	01987
	Thomson	01582
	Time Warner	01376, 01877, 02187
	ToongTV	03322
	Topfield	02981
	True Visions	03075
<b>U</b>	UPC	01582
<b>V</b>	Vidéotron	01877
	Virgin Media	01987, 02563, 03265
	VTR	01376
<b>W</b>	Welho	02832
	WideOpenWest	01877
<b>Y</b>	YBN	03322

IP TV		
<b>A</b>	ADB	02254
	Alcatel-Lucent	02901
	Amino	01481, 02482
	AT&T	00858
	au	03445, 03485, 03534
<b>B</b>	BBTV	02516, 02518, 02980
	Bell	01998
	BT	02294
<b>C</b>	Celrun	02959, 03196, 03442
	Channel Master	03118
	Chunghwa	01917
	Cisco	00858, 02345, 02378, 03028
	ClubInternet	02132
	CNS	02980
<b>D</b>	DASAN	02683
<b>E</b>	Echostar	03452
	Entone	02302
<b>G</b>	GDCA TV	02980
<b>H</b>	Hana TV	02681, 02959
	HDT	02959
	Humax	02683
	KDDI	03445, 03485, 03534
<b>K</b>	Kiss	02132
	KoolConnect	01481
	KT	02683
<b>L</b>	LG	03196
	LG U+	02682, 03196
<b>M</b>	Mega	02683
	Mega TV	02683

	Minerva Networks	03118
	MIO	02275, 02802
	mio TV	02275, 02802
	Mitsubishi	03274, 03485
	Motorola	01376, 00476, 00858, 01998, 02275, 02378, 03445, 03534
	MTS	01998
	MyLGTV	02682
<b>N</b>	Neuf TV	03107
	Now TV	02014
	NTT	03237, 03274
<b>O</b>	Oi TV	03452, 03454
	OllehTV	02683
	Orange	02407
<b>P</b>	Pace	03454
	Philips	02174
	Pirelli	02944
<b>Q</b>	Qook TV	02683
	Qtel	01822
<b>S</b>	Sagem	02407
	Samsung	02174, 02407, 02683
	Sasktel	01998
	Scientific Atlanta	00858, 02345, 03028
	SetaBox	01917
	SFR	03107
	SingTel	01998, 02275, 02802
	SK Broadband	02959, 03442
	SK BTV	03442
	SKBtv	02681, 02959
	SKY Deutschland	02620

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

	Skyworth	02893
	SureWest	01481, 01998
<b>T</b>	T-Home	02132
	Telefonica	02901, 02944, 03028
	Telus	02345
	Thomson	02174, 02407
<b>U</b>	U+	03196
	Unihan	02453
<b>V</b>	Verizon	02378
<b>W</b>	WNC	03118
<b>Y</b>	Yuxing	02014
<b>Z</b>	Zhong Hua Dian Xin	01917
	ZyXEL	02944

## SAT

<b>@</b>	@sat	01300
	@Sky	01334
<b>A</b>	ABsat	00713
	Acoustic Solutions	01284
	ADB	00887, 01887
	AEG	02738, 02813
	Agora	01284
	Airis	01993
	Akura	01626
	Alba	00713, 01284, 02034
	Alltech	00713
	Allvision	01334
	Altech UEC	02059
	Amitronica	00713

	Amstrad	00847, 01175, 00713, 01662, 01693
	Anglo	00713
	Ankaro	00713
	Ansonic	02418
	Apro	01672
	Arena	01736
	Arnion	01300
	ASA	00740
	ASCI	01334
	ASLF	00713
	AssCom	00853
	Astra	00713
	Astell	01986, 02418
	Astro	00173, 00658, 01099, 01100, 01836, 02026, 02627
	Atlanta	02418
	Atom	02289
	Audiola	02418
	Audioline	01672
	Aurora	00879
	Austar	00879
	Auvisio	02531
	Avanit	01631
	Awa	02418
	Axil	01413, 01777, 01993, 02418
	Axitronic	01626
<b>B</b>	B.net	01672
	B@ytronic	00740
	Bell	00775
	Belson	02418

	Best Buy	01993, 02728
	Black Diamond	01284
	Blaupunkt	00173
	Blue Sky	00713
	Boca	00713, 02026, 02308, 02458, 02797, 02813
	Boshmann	01413, 01631
	Boxer	01692, 01957
	Brainwave	00658, 01672
	Broco	00713
	BskyB	00847, 01175, 01662, 01693
	Bubu Sat	00713
	Bush	01284, 01291, 01626, 01672, 01935, 01993, 02034, 02376, 02418, 02813
<b>C</b>	Canal Digital	00853, 01334, 01780
	Canal+	00853, 02657
	CanalSat	00853, 02657
	CDV	01993
	Century	00856
	CGV	01413, 01567, 02034
	Chess	00713, 01334, 01626, 02026
	Signal	02289, 03128
	CityCom	00299, 00658, 01176
	Classic	01672
	Clatronic	01413, 02738
	Clayton	01626
	CMX	02205
	Cobra	02531
	Com Hem	01176, 01915, 02357
	Comag	01413, 01886, 02026, 02308, 02458, 02797, 02813

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Comsat	01413
Comwell	01956
Coomax	02531
Coship	01672
Croner	02813
Crown	01284
CS	01631
Cyfra+	01409
Cyfrowy Polsat	00853, 02262, 02527
<b>D</b> D-box	00723, 01114
Daewoo	00713
DAK	01993
Dantax	01626
DASAN	03321
Denver	02418
Dgtec	01631, 02418
Di-Way	02289
Dicra	02738
Digenius	00299
Digi	02026
Digitality	01334
DigiCrystal	02978
Digihome	01284, 01935, 02034
DigiLogic	01284, 02034, 02241
DigiMax	02273
DigiQuest	01300, 01631, 02278, 02738
Digital	02273, 02308
DigitalBox	01100, 01631, 01886, 02289
Digiwave	01631
Dikom	02531
Dilog	01780, 01957

DiPro	02278
DirecTV	01377, 00392, 00566, 00099, 03377
Dish Network	00775
Dishpro	00775
DishTV	01300, 01780
Diunamai	02531
DMT	03321
Doro	01672
DRE	01176
Dream Multimedia	01237, 01652, 01923
DSE	02418, 02813
DSTV	00879
Dual	02034
Durabrand	01284, 02034, 02241
DVX	01993
Dyon	02738, 02813
<b>E</b> Echostar	00775, 00853, 00713, 01323, 01409, 02262, 02272, 02527
Eco-Star	01413
Edision	01631, 02306, 02712
Ei8ht	02978
Einhell	00713
Elap	00713, 01413, 01567
Elbe	02418
Electron	01956
Elisa	01322
Elless	00740
Elsat	00713
Embratel	02796
Energy Sistem	01631, 02289, 02418

Engel	00713, 01993
Etisalat	02443
Europhon	00299, 00713, 01334
Europsat	01413, 01611
Eurosat	01886
Eurosky	00299, 00740
Eutelsat	00713
Eutra	00740
Evesham Technology	02034
<b>F</b> Fagor	01611
Fenner	00713
Ferguson	01291, 01935
Finepass	01780
Finlux	01626
FinnSat	00740, 01195, 01197
Flair Mate	00713
FMD	01413
Fortec Star	01631
Foxtel	00879, 01176, 01356
Fracarro	00713
Freesat	02376
Freesat+	02443
freeview	02982
Fte Maximal	00713, 01886
Fuba	00173, 00299, 02750
Fuji Onkyo	01631, 02728
<b>G</b> Galaxis	00853, 00879
Galaxy	01956
GE	00566
General Instrument	00869

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

General Satellite	01176
Globo	00740, 01334, 01429, 01626, 02026, 02273
GoGen	02738
GOI	00775
Gold Box	00853
Gold Vision	01631
GoldMaster	01334, 01722
Goodmans	01284, 01291, 02034, 02376
Gradiente	00856, 00099, 00887
Gran Prix	00740
Grandin	01626
Grococ	01409
Grundig	00847, 00853, 00173, 00879, 01284, 01291, 01672, 01780, 02034, 02376
<b>H</b> Haier	02418
Hailo	02289
Hallo	01626
Hama	01567
Handan	01780, 01957
Hanseatic	01099, 01100
Hauppauge	01672
HB	01736
HDT	01255, 03321
Hiro	01886
Hirschmann	00173, 00299, 00740, 01886, 02026
Hitachi	01284, 02034
Homecast	01736
Hornet	01300
HTS	00775

Hughes Network Systems	01377
Humax	01377, 03321, 02736, 02443, 02408, 02357, 02289, 02144, 01989, 01915, 01882, 01808, 01788, 01675, 01427, 01255, 01176
<b>I</b> i-Box	01652
ID Digital	01176
ID Sat	01334, 02289
Illusion	01631
Imperial	01195, 01197, 01334, 01429, 01672
Indovision	00856, 00887, 01255, 01887, 01989
iNETBOX	01237, 01652
Inno Hit	01626
Innova	00099
Inves	01993
inVion	02418
iotronic	01413
IQ	02813
ISkyB	00887
ITT	02418
ITT Nokia	00723
<b>J</b> J-Point	01836
Jaeger	01334
Jerrold	00869
Jiuzhou	03140
JVC	00775
<b>K</b> K-SAT	00713
KabelBW	01195, 01197, 01882, 01915
Kamm	00713

Kaon	01300, 02697
Kathrein	00173, 00658, 00713, 01561, 01567, 02263, 02569
Kenwood	00853
König	01567, 01631, 02289
Koscom	01956
KPN	01986
Kreiling	00658, 01626
Kreismeyer	00173
KT	03321
<b>L</b> L&S Electronic	01334
LaSAT	00173, 00299, 00740
Lauson	02531
Lava	01631
Leiko	01626
Lemon	01334
Lenco	00713
Lenoxx	01611
LG	03193, 03321
Lifesat	00299, 00713
Linsar	01284
Listo	01626
Lodos	01284
Logik	01284, 02034
LogiSat	02797, 02813
Lorenzen	00299
Luxor	01935, 02034
<b>M</b> Macab	00853
Magic TV	02982
Majestic	02738
Manata	00713

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Manhattan	01300
Maplin	02034
Marusys	02799
Maspro	00173, 00713
Matsui	00173, 01284, 01626
Maxell	03438
Maximum	01334, 01672, 01986, 02813
Mediabox	00853
Mediacom	01206
MediaSat	00853
Mediaset	02750
Medion	00299, 00713, 00740, 01334, 01626, 02026, 02797
Medison	00713
Mega TV	03321
MegaSat	01631, 01886, 02289, 02813
Metronic	00713, 01334, 01413, 01631, 01986, 02418, 02738
Metz	00173
MiCO	01993
Micro	00713, 02797, 02813
Micro electronic	00713, 02308, 02813
Micro Technology	00713
Micromaxx	00299
Microstar	00299
Microtec	00713
Morgan's	00713, 02026
Motorola	00869, 00856, 03469
Movistar	02262, 02263, 02272, 02527, 02761, 03029
Multichoice	00879, 02059, 02060

myfreeviewHD	02982
Mysat	00713
Neom	01993
<b>N</b> NEOTION	01334
NET	02262
Netgem	01322
Netsat	00099, 00887
Neuf TV	01322
Neuhaus	00713
Neuling	02458
Neusat	00713
Next Level	00869
Nextvision	01956
NextWave	01956
Nikkai	01993
Nikko	00723, 00713
Nilox	02278
Nokia	00853, 00723, 01023
Nordmende	01611
NPG	01631, 02289, 02531
<b>O</b> Olleh-Skylife	03321
OllehTV	03321
Omni	01993
Onn	01284, 02034, 02241
Openbox	01956
Opensat	01956
Optex	00713, 01413, 01611, 01626
Opticum	02273
Optus	00879, 01356
Orbis	01334
Orbitech	01099, 01100, 01195, 01197

Orton	02273
<b>P</b> Pace	00847, 00853, 00887, 01175, 03469, 03111, 02796, 02657, 02060, 02059, 01887, 01693, 01682, 01662, 01356, 01323
Pacific	01284
Palcom	00299, 01409, 01611
Panasat	00879
Panasonic	00847, 01304, 03239, 03484, 03939
Panda	00173
Pass	01567
peekTOn	01993, 02418
Philips	00856, 00099, 00853, 00173, 01114, 00887, 01499, 01672, 01836, 02176, 02619, 03469
Phoenix	01956, 02418
Phonotrend	01780
Pino	01334
Pioneer	00853
Pixel Magic	02982
Pixela	03409
PLDT	02836
PMB	00713, 01611
Premium	01736
Pro Basic	00853, 02205, 02531
Proline	01284
Proscan	00392, 00566
<b>Q</b> Qook TV	03321
Qook-SkyLife	03321
Quelle	00299
<b>R</b> RadioShack	00869
Radix	01255



AVR	CBL/SAT group	TV group	VCR/PVR group	BD/DVD group	Audio group
RCA	00392, 00566, 00855, 01291	SCS	00299, 00740	SkyLife	01255, 03321
RiksTV	01692	Sedea Electronique	01206, 01626	Skymaster	00713, 01334, 01409, 01545, 01567, 01611, 02205, 02241, 02409, 02728
Roadstar	00853, 00713	Seeltech	01993	Skymax	01413
Rollmaster	01413	SEG	01284, 01626, 01993, 02034	Skypex	00740
Ross	02540	Servimat	01611	Skyplus	01175, 00740, 01334, 02026
Rover	00713	ServiSat	00713	SkySat	00713, 01100
Rownsonic	01567	Set-One	02728	Skyvision	01334, 02797
<b>S</b> SAB	01300, 01631, 01956	Shark	01631	Skyworth	01631
Saba	00740, 02205	Sharp	01935, 02034	SL	00299, 00740, 01672, 02026
Sagem	01114, 01690, 01692, 03029	Shaw Direct	00869	SM Electronic	00713, 01409
Sagemcom	01692	Sherwood	01409	Smart	00713, 01413, 01631, 02289
Saivod	02418	Siemens	00173, 01334, 01429, 01626, 01657, 01672, 02418	Sony	00847, 00853, 01558, 02299, 03049, 03446, 03448
Samsung	01377, 00853, 01175, 01206, 01255, 01662, 01682, 03321	Sigmatek	02418, 02813	Star	00887
Sansui	01545	SignalMAX	01956	Star Choice	00869
Sanyo	01626, 03436, 03437	Silva	00299	Starland	00713
Sat Control	01300	Silva Schneider	00740	Stream System	01300
Sat Industrie	01611	SilverCrest	02026, 02308, 02458	Strong	00853, 00879, 00713, 01284, 01300, 01409, 01626, 02235, 02418, 02813
Sat Team	00713	Skantin	00713	Sunny	01300
SAT+	01409	SKR	00713	Sunsat	00713
SatCatcher	01956	SKY	00856, 00099, 00847, 00887, 01175, 01358, 01499, 01662, 01693, 02619, 03469	Sunstech	01993, 02738
Satec	00713	Sky Brasil	00856, 00887, 01358, 01499, 02619, 03111	Supernova	00887
Satlink	02273	SKY Deutschland	00723, 01429, 02176	Supratech	01413, 01993
Satplus	01100	SKY Italia	00853, 01356, 01693	Systec	01334
SatyCon	01631	SKY Mexico	00856, 00887, 01358, 02619, 03469	Sytech	02418
Schaub Lorenz	02034, 02418	SKY PerfecTV!	02299, 03049, 03484, 03939	<b>T</b> Tatung	03117
Schneider	01206	SkyCable	01631, 01957	TBoston	02418
Schwaiger	00740, 01334, 01429, 01631, 01672, 02308, 02458, 02797, 02813			Teac	01322, 01957, 02813
Scientific Atlanta	01980				

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Technical	01626
Technicolor	03469
Technika	01284, 01672, 02034
TechniSat	01099, 01100, 01195, 01197, 01322
Technoit	02278
Technosat	01206
Technosonic	01672
Technotrend	01429, 01672, 02263
Techwood	01284, 01626, 01935, 02034
TELE System	01409, 01611, 02750, 02813
Telefonica	01692, 02262, 02263, 02272, 02527, 02761, 03029
Telestar	01099, 01100, 01195, 01197, 01334, 01626, 01672, 02540
Televes	01300, 01334
Televisa	00887
Telsey	02738
TelSKY	02540
Tevion	00713, 01409, 01672, 01993, 02026, 02205, 02813
Thomson	00392, 00847, 00853, 01175, 00713, 01291, 01662, 01935, 02176, 02619, 03469
Tiny	01672
Titan	01886, 02205
Tividi	01429, 01736
TNT SAT	01692
Tonna	00713, 01611, 02458
Topfield	01206, 01545, 01722, 01783, 01824, 01986
Toshiba	01284, 01429
Transparent Video Systems	01780, 01957

Triax	00853, 00713, 01291, 01413, 01611, 01626, 01631, 01886, 02026
Tricolor TV	01176
True Visions	02408, 03140
TT-micro	01429
Turnsat	00713
TVB	01989
TWF	01993
Twiner	00713, 01611
U	UEC 00879, 01356, 01358
United	01626, 02278, 02418
Unitymedia	01429, 01882
Univers	01886
Universum	00173, 00299, 00740, 01099
Unixbox	01652
V	Vantage 02297
Vaova	01993
Variosat	00173
VEA	02418
Vestel	01284, 02034
VH Sat	00299
Via Embratel	02796
Viasat	01195, 01197, 01682, 02235
Viola Digital	01672
Vision	01626, 01886
Visiosat	00713, 01413
Vitecom	01413, 02531
Viva	00856
Vivax	02418
Volcasat	02418

Voom	00869
Vu+	02799
W	Wavelength 01413
Welho	02357
Wharfedale	01284, 01935, 02034
Winix	02278
Wintel	00299
Wisi	00173, 00299, 00740, 01986
Woxter	02418, 02813
X	Xoro 02738, 02813
Xsat	00847, 00713, 01323
Xtreme	01300
Y	Yakumo 01413
Yamada	01993
Yes	00887, 01887
Yess	02978
Z	ZapMaster 00740
Zehnder	00740, 01334, 01413, 01631, 01777, 02034, 02289
Zenith	00856, 03469
Ziggo	01499, 01657, 02443
Zinwell	02761

## CBL/SAT/PVR Combination

C	Com Hem	01176, 02357
F	Foxtel	01356
H	Handan	01957
	Humax	01176, 02357, 02443
K	Kaon	01300
	Kathrein	01561, 02569
P	Pace	01356

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

<b>S</b>	Siemens	01657
<b>T</b>	TechniSat	01195, 01197
	Topfield	01545, 01783
<b>V</b>	Vantage	02297
<b>W</b>	Welho	02357
<b>Z</b>	Ziggo	01657, 02443

## SAT - IP TV

<b>D</b>	DMT	03321
<b>K</b>	KT	03321
<b>L</b>	LG	03321
<b>O</b>	Olleh-Skylife	03321
	OllehTV	03321
<b>Q</b>	Qook-SkyLife	03321
<b>S</b>	SkyLife	03321

## SAT/PVR Combination

<b>@</b>	@sat	01300
<b>A</b>	AEG	02738, 02813
	Amstrad	01175, 01662, 01693
<b>B</b>	B@ytronic	00740
	Bell	00775
	Boca	02308, 02797, 02813
	Boxer	01957
	BskyB	01175, 01662, 01693
<b>C</b>	Canal+	02657
	CanalSat	02657
	Comag	02308, 02797, 02813
	Cyfrowy Polsat	02527
<b>D</b>	Digihome	02034

	DigiQuest	01300
	Digital	02308
	Dilog	01957
	DirecTV	01377, 00392, 00099, 03377
	Dish Network	00775
	Dishpro	00775
	Dream Multimedia	01237, 01923
	Dyon	02738, 02813
<b>E</b>	Echostar	00775, 02272, 02527
	Edision	01631, 02712
	Embratel	02796
	Etisalat	02443
	Eurosky	00740
<b>F</b>	Foxtel	01356
	Freesat+	02443
	Fuji Onkyo	01631
<b>G</b>	Goodmans	02034
<b>H</b>	Handan	01957
	Hirschmann	00740
	Hitachi	02034
	Humax	01377, 01176, 01427, 01675, 01788, 01808, 02357, 02443
<b>I</b>	ID Sat	01334
	iNETBOX	01237
<b>J</b>	JVC	00775
<b>K</b>	Kaon	01300
	Kathrein	00658, 01561, 02569
<b>L</b>	LaSAT	00740
	LogiSat	02797, 02813
	Luxor	01935

<b>M</b>	Marusys	02799
	Maxell	03438
	Maximum	01334, 02813
	Mediacom	01206
	Medion	00740, 02797
	MegaSat	01631, 02813
	Micro	02797, 02813
	Micro electronic	02308
	Motorola	00869
	Movistar	02272, 02527, 03029
	Multichoice	02059, 02060
<b>N</b>	NEOTION	01334
	Nokia	01023
<b>O</b>	Omni	01993
	Orbitech	01195, 01197
		01175, 01356, 01662, 01682, 01693, 02059, 02060, 02657, 02796
<b>P</b>	Pace	
	Panasonic	01304, 03484, 03939
	Philips	00099
	Proscan	00392
<b>R</b>	Ross	02540
<b>S</b>	Sagem	01692, 03029
	Samsung	01377, 01175, 01206, 01662, 01682
	Sansui	01545
	Sanyo	03436, 03437
	Sat Control	01300
	Schneider	01206
	Schwaiger	00740, 02308
	Sedea Electronique	01206

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

SEG	02034
Sharp	01935, 02034
Shaw Direct	00869
Siemens	01657
SilverCrest	02308
SKY	01175, 01358, 01662, 01693
Sky Brasil	01358
SKY Italia	01356, 01693
SKY PerfecTV!	02299, 03484, 03939
SkyCable	01631, 01957
Skymaster	01545
Skypex	00740
Skyplus	01175, 00740, 01334
Skyvision	02797
Skyworth	01631
SL	00740
Smart	01631
Sony	02299
Star Choice	00869
Stream System	01300
Strong	01300, 02813
Sunny	01300
<b>T</b> Tatung	03117
Teac	01957
TechniSat	01195, 01197
Technosat	01206
Telefonica	01692, 02272, 02527, 03029
Telestar	01195, 01197, 02540
TeISKY	02540
Thomson	01175, 01662, 01935
TNT SAT	01692

Topfield	01206, 01545, 01783, 01824
<b>U</b> UEC	01358
<b>V</b> Vantage	02297
Via Embratel	02796
Viasat	01195, 01197, 01682
Vu+	02799
<b>W</b> Wisi	00740
<b>X</b> Xoro	02738, 02813
Xtreme	01300
<b>Y</b> Yamada	01993
<b>Z</b> Zehnder	00740, 01777, 02034

## MEDIA PLAYER/Video - Accessory

<b>A</b> A.C.Ryan	02709
ABS	01272
Acer	01272
Alienware	01272
Apple	02615
Asus	02987
<b>C</b> Claritas	01272
CyberPower	01272
<b>D</b> Daily Media	01272
Digitech	02260
<b>E</b> Elonex	01272
Eminent	02260
Emtec	02709
<b>F</b> Fantec	02709
Fujitsu Siemens	01272
<b>G</b> Gateway	01272
<b>H</b> Hewlett Packard	01272

hFX	01272
Howard Computers	01272
Hush	01272
<b>I</b> iBUYPOWER	01272
iconBIT	02709
ISTAR	02260
<b>L</b> LaCie	03345
LG	03373
Linksys	01272
<b>M</b> Magnavox	03339
MedeBer	02709
Media Center PC	01272
Microsoft	01272, 01805
Mind	01272
<b>N</b> Netgear	03292, 03324
Niveus Media	01272
Northgate	01272
<b>P</b> Packard Bell	01272
Patriot	03307
Philips	01272, 03526
PopBox	02260
Popcorn Hour	02260
<b>R</b> RCA	03335
Ricavision	01272
Roku	02371, 03061
<b>S</b> Samsung	01967
Seagate	02698
Sony	01272, 02713
Stack 9	01272
Systemax	01272

<b>T</b>	Tagar Systems	01272
	Toshiba	01272
	Touch	01272
	Trust	01272
<b>V</b>	VIA Technologies	01272
	Viewsonic	01272
	Voodoo	01272
<b>W</b>	Western Digital	02558
	Woxter	02709
<b>X</b>	Xbox	01272, 01805
<b>Y</b>	Yamaha	02865
<b>Z</b>	ZT Group	01272

## TV group

### TV

<b>8</b>	888	10264
<b>A</b>	A.R. Systems	10556, 10037
	Accent	10037
	Acer	11339
	Acoustic Solutions	11037, 11523, 11667, 11865, 12676
	Action	10650
	Addison	10653, 10108, 10092, 11150
	Admiral	10093, 10463, 10264, 10179, 13485
	AEG	11037, 11163, 11324, 11556, 12197
	Agashi	10264
	Aiko	10037, 10264, 10092
	Aim	10706, 10037
	Aiwa	11910, 11916
	Akai	10812, 10702, 10765, 10178, 10030, 10556, 10037, 10548, 10714, 10264, 10208, 11326, 11413, 11675, 11865, 12414, 12676, 13183
	Akiba	10037
	Akira	11243, 12241
	Akito	10037
	Akura	10171, 10037, 10714, 10668, 11037, 10264, 11363, 11498, 11556, 11585, 11667, 11687, 11770, 11983
	Alaron	10179

Alba	10037, 10714, 10668, 11037, 10036, 10587, 10443, 10474, 11585, 11865, 12104, 12676
Alien	11037
Allstar	10037
America Action	10180
Amstrad	10171, 10037, 11037, 10264
Anam	10250, 10180, 10037, 10650
Andersson	11163, 11585
Anglo	10264
Anhua	10051
Anitech	10037, 10264, 10474
Ansonic	10037, 10668
AOC	10093, 10180, 10178, 10030, 10625, 10108, 10092, 10179, 10474, 11150, 11365, 11589, 12014, 12087, 12214, 12621
Aolinpike	10264
Apex Digital	10765, 10767, 12397
Ardem	10037, 10714
Arena	10037
Aristona	10556, 10037
ART	11037
Art Mito	11585
ASA	10179
Asberg	10037
Astra	10037
Asuka	10264
Asus	12175, 13340
ATD	10698

Atlantic	10037
Audinac	10180
Audiosonic	10037, 10714, 10264, 11675, 11983, 12104
Audioton	10264
Audiovox	10180, 10092, 11276, 11564, 11865, 11937, 12121, 12513
Audioworld	10698
Auria	12087, 12277
Aventura	10171
Awa	10264, 10036, 10108, 12241
Axion	11937
Axxon	10714
<b>B</b>	
Baihe	10264
Baile	10661
Baird	10208
Bang & Olufsen	10620
Baohuashi	10264
Barco	10556
Basic Line	10556, 10037, 10668, 11037, 11163
Baur	10037, 10195, 10512
Baysonic	10463, 10180
BBK	11523
Beaumark	10178
Beijing	10812, 10264, 10208, 10661
Beko	10037, 10714, 10808, 11652, 12125
Bell & Howell	10017
Belson	10698, 12032, 12241

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Belstar	11037		10556, 10037, 10714, 10668, 11037, 10698, 10264, 10036, 10587, 12214, 12241, 12676, 12125, 12104, 12053, 12032, 12007, 11983, 11916, 11865, 11687, 11667, 11652, 11645, 11589, 11585, 11556, 11243, 10661, 10443, 10208	Chimei	11666
BenQ	11523, 11756, 12449, 12730			Ching Tai	10092, 10179, 10474
Bensten	11326	Bush		Chun Yun	10000, 10180, 10706, 10092, 10179, 10474, 11150, 11687, 11756
Beon	10037			Chunfeng	10264
Berkshire	10047			Chung Hsin	10180, 10053, 10036, 10108, 10474, 11150
Berthen	10556, 10668	Byd:sign	11311	Cineral	10092
Bestar	10037	Cameron	11523	Cinex	11556
Bestwell	11326	Camper	10037	Citizen	10180, 10030, 10092
Bexa	12493	Candela	13546	Clarion	10180
BGH	10898	Candle	10030	Clarivox	10037
Black Diamond	11037, 10587, 11163	Capetronic	10030	Clatronic	10037, 10714, 10264, 11324
Blaupunkt	10195, 10036	Capsonic	10264	Clayton	11037
Blue Sky	10556, 10037, 10625, 10714, 10668, 11037, 10624, 11243, 11314, 11324, 11363, 11652, 11916, 12153	Carad	10668, 11037	Coby	12306, 12315, 12340, 12343, 12344, 12345, 12347, 12348, 12350, 13478
BlueH	11745	Carena	10037	Commercial Solutions	10047, 11447
Bluetech	12561	Carnivale	10030	Condor	10037, 10264
Boca	11652	Carrefour	10037, 10036	Conia	11498, 11523, 11687, 12032
bogo	12561	Cascade	10037	Conrac	10808
Boman	11324	Casio	10037	Conrowa	10156, 10698, 10264, 11156
Bork	11363	Cathay	10037, 10474	Contec	10180, 10037, 10036
BPL	10037, 10208	CCE	10037	Contex	13309
Bradford	10180	Celebrity	10000	Coradir	12844
Brandt	10625, 10714, 10560	Celera	10765	Cosmel	10037
Brinkmann	10037, 10668	Celestial	10767, 11243	CPTEC	10625, 11363
Brionvega	10037	cello	11770	Craig	10180, 13423
Britânia	12414	Centrum	11037	Crosley	10000
Broksonic	10463	Centurion	10037	Crown	10180, 10053, 10037, 10714, 10668, 11037, 10208, 11652
		Changcheng	10051, 10264, 10661		
		Changfeng	10264		
		Changhong	10156, 10765, 10264, 10508, 10767, 11156, 11243, 11498, 11910		

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

D

CTX	11756
Curtis	11326, 12352, 12397, 12466, 12855, 13228, 13577
Curtis Mathes	10047, 10051, 10093, 10702, 10030, 11661, 11347
CXC	10180
Cyberpix	11667
Cytron	11326
Cytronix	11298
D-Vision	10556, 10037, 12197
Daenyx	10180, 10179
Daewoo	10180, 10178, 10030, 11661, 10556, 10037, 10634, 10108, 10092, 10474, 10624, 10661, 11150, 12098
Dansai	10037, 10036, 10208
Dantax	10714, 11037, 11163, 11652, 11916
Datsura	10208
Dawa	10037
Daytron	10180, 10037
Dayu	10661
De Graaf	10548, 10208
DEC	11326
Decca	10037
Dell	11264, 11863
Denko	10264
Denver	10037, 10587, 11770, 12197
Desmet	10037
Dew	11770
Diamant	10037
Diamond	10706, 10698
Digatron	10037

Digihome	11667
Digiline	10037, 10668
Digisonic	11826
Digitor	10037, 10698
Dikom	12561
Dish Network	11948
Disney	11665, 11892
diVision	12197
Dixi	10037
DL	10587, 11326, 11363
DMTech	11937
Domeos	10668
Dream Vision	11704
Drean	10037
DSE	10698, 10767, 11326, 11556, 12241
Dual	10037, 11037, 11163, 11585, 11667, 12032, 12241, 12676
Dumont	10017
Durabrand	10463, 10180, 10178, 10171, 10714, 11037, 11652, 11665
Dux	10037
DX Antenna	11817, 13460
DX Broadtec	13460
Dynaconnective	12811
Dynatron	10037
Dynex	11810, 12049, 12184
E.S.C.	10037, 10474
E:max	11324
Easy Living	11666, 12104
ECE	10037
Elbe	10556, 10037

E

Electroband	10000
Electrohome	10463, 11670
Elekta	10264
Elektra	10017, 11661
Element	11687, 11886, 12183, 12964, 13559
Elfunk	11037, 11208
ELG	10037
Elin	10037, 10548
Elite	10037
Elta	10264, 10474
Emerson	10463, 10180, 10178, 10171, 11661, 10037, 10714, 10668, 10624, 11394, 10179, 11665, 11864, 11886, 11944, 11963, 12183
Envision	10030, 11365, 11506, 11589, 12014, 12087
Erres	10037
ESA	10812, 10171, 11944, 11963
Essentials	12486
Ether	10030
Eurofeel	10264
Euroman	10037, 10264
Europa	10037
Europhon	10037
Evesham Technology	11248, 11667
Evolution	11756
Evotel	12561
Excello	11037, 11326
Exquisit	10037
F&U	12676

F



AVR	CBL/SAT group	TV group	VCR/PVR group	BD/DVD group	Audio group
Fair Mate	11326	Futronic	10264		10556, 10037, 10625, 10714, 10560, 10668, 10634, 11037, 10264, 10036, 12053, 12393, 12676, 11983, 11916, 11687, 11667, 11645, 11585, 11523, 11163, 10808, 10661, 10624, 10179
Feiyan	10264	Futuretech	10180	Goodmans	
Ferguson	10053, 10037, 10625, 10548, 10560, 10195, 11037, 10443, 11585, 11865, 12053	<b>G</b> G-Hanz	12449		
Fidelity	10171, 10037, 10264, 10474, 10512	G-HanzS	11363	Gorenje	11585, 12676
Finlandia	10548, 10208	Gaba	11037	GPX	10179, 13402
Finlux	10556, 10037, 10714, 10179, 10808, 11248, 11556, 11667, 12676	Galaxi	10037	Gradiente	10053, 10037, 11804
Firstline	10556, 10037, 10714, 10668, 11037, 10208, 10624, 10808, 11363	Galaxis	10037	Graetz	10714, 11163
Fisher	10047, 10036, 10208	Gateway	11756	Granada	10037, 10548, 10560, 10036, 10108, 10208
Flint	10037, 10264		10047, 10051, 10093, 10180, 10765, 10178, 10030, 11447, 11454, 10625, 10560, 10092, 11347, 11547	Grandin	10556, 10037, 10714, 10668, 11037, 10624, 11298, 11652
Fluid	12964	GE		Grundig	10706, 10556, 10037, 10195, 10036, 10587, 10443, 11223, 11523, 11645, 11667, 11916, 12007, 12053, 12125, 12561
Formenti	10037	GEC	10037	Grunkel	11163
Fortress	10093	Genesis	10037	Grunpy	10180, 10179
Fraba	10037	Genexxa	10037	GVA	11326, 11363, 12098
Freesat	11636	Gericom	10808, 11298	<b>H</b> H & B	10808
Friac	10037	GFM	10171, 11665, 11864, 11886, 11963	Haaz	10706
Frigidaire	11826	Gibraltar	10017, 10030	Haier	10037, 10698, 10587, 10508, 11748, 11749, 11983, 12214, 12309, 12449, 13382
Frontech	10264, 10474	Gibson	11826	Haiyan	10264
Fujimaro	11498, 11687	Gilma	12449	Halifax	10264
Fujimaru	11687	Gintai	10474, 11150	Hallmark	10178
Fujitsu	10179	Global Home	10767	Hankook	10180, 10178, 10030
Fujitsu Siemens	10808, 11163, 11248, 11298, 11666	Godrej	11585	Hannspree	11348, 11745, 11826
Funai	10000, 10180, 10171, 10714, 10668, 11037, 10264, 10179, 11271, 11394, 11666, 11817, 11963	Gold	11770	Hanseatic	10556, 10037, 10625, 10714, 10634, 10661, 10808
Furi	10264	Gold Vision	10661	Hantarex	10037, 12197
		Goldfunk	10668		
		GoldStar	10178, 10030, 10037, 10714, 10474, 11150, 11910		

AVR	CBL/SAT group	TV group	VCR/PVR group	BD/DVD group	Audio group
Hantor	10037	Hornymphon	10037	Intervision	10037, 10264
Harley Davidson	10179	Hua Tun	11150	Irradio	10037
Harvard	10180	Huangshan	10264	IRT	11661, 10698
Harwood	10037	Huanyu	10264, 11910	Isis	12676
Hauppauge	10037	Huaqiang	10264	Isukai	10037
Havermy	10093	Huari	10264	iSymphony	13094
HB	10714, 11324	Hugoson	11666	ITS	10037, 10264
HCM	10037, 10264	Huodateji	10051	ITT	10548, 10179, 10208, 11523, 12125, 12676
Heran	11826	Hypson	10556, 10037, 10714, 10668, 11037, 10264	ITT Nokia	10180, 10548, 10179, 10208
Herosonic	11826	Hyundai	10706, 11037, 10698, 10767, 11326, 11523, 11556, 11770, 12676	ITV	10037, 10264
Highline	10037, 10264	Iberia	10037	J:COM	12811
Hikona	10474, 11983	ICE	10037, 10264	JCB	10000
Himitsu	10180	iDEAL	11556	JCM	12256
Hinari	10037, 10264, 10036, 10179, 10208, 10443	iLo	11286, 11394, 11665, 11684, 11990	Jean	10156, 10051, 10036, 10092, 10179, 10474
HiPlus	11826	Imperial	10037	Jensen	11326
Hisawa	10714	Imperial Crown	10264, 10661	Jiahua	10051
Hisense	10156, 10556, 10508, 10208, 11156, 11208, 11314, 11363, 12098, 12183, 12355, 12419	Indiana	10037	JiaLiCai	10264
Hitachi	10156, 10150, 10178, 10030, 11145, 11256, 10037, 10548, 10634, 11037, 10036, 10108, 10508, 11643, 11667, 11854, 12170, 12207, 12214, 12676, 13317, 13456, 11585, 11576, 11163, 11156, 11150, 10744, 10679, 10578, 10474, 10179, 10092	Initial	11990	Jinfeng	10051, 10208
Hitachi Fujian	10150, 10108	Inno Hit	11037, 11163, 11585	Jinhai	11910
Hitec	10698	Innova	10037	Jinque	10264
Höher	10714, 11163, 11556	Innowert	11298	Jinta	10264, 11910
Hongmei	10093, 10264, 11910	Insignia	10463, 10171, 11326, 11423, 11564, 11892, 11963, 12049, 12184, 12417	Jinxing	10156, 10556, 10037, 10698, 10264
Hongyan	10264	Inspira	11556	JMB	10556, 10634, 10443, 12676
		Inteq	10017	Jubilee	10556
		Interbuy	10037, 10264	Juhua	10264
		Interfunk	10037, 10512	JVC	10093, 10463, 10053, 10036, 10650, 10653, 10508, 11253, 11428, 11601, 11774, 12271
		Internal	10556, 10624	Kaige	10264

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Kaisui	10037
Kangchong	11910
Kangli	10264, 10661
Kangyi	10264
Karcher	10714, 10264, 11324, 11556, 12125
Kathrein	10556
KDS	11498, 11687
KEC	10180
Ken Brown	10463
Kendo	10037, 11037, 11585, 12676
Kenia	10030
Kennex	11037
Kenwood	10030
Keymat	11326
Khind	10706, 10661
Kioto	10706, 10556
Kiton	10037, 10668
KLH	10765, 10767
KLL	10037
Kneissel	10556, 10037
Kolin	10180, 10150, 10053, 10037, 10036, 10108, 10474, 11150, 11240, 11331, 11610
Kolster	10037
Kongque	10264
König	10037
Konka	10037, 10714, 10587, 10725, 13419
Korpel	10037
Kosmos	10037
KTV	10180, 10030

Kuaile	10264
Kunlun	10051, 10264, 10208, 10661
Küppersbusch	12676
<b>L</b> L&S Electronic	10714, 10808
Lavic	11363
Lavis	11037
Lecson	10037
Lenco	10037, 11037, 10587, 10474, 11983
Leyco	10037, 10264
LG	10017, 11265, 10178, 10030, 11447, 10556, 10037, 10714, 10698, 10108, 12731, 12424, 12362, 12358, 12182, 11840, 11663, 11423, 10856, 10474
Liesenkötter	10037
Lifetec	10037, 10714, 10668, 11037
Linetech	12676
Linsar	11585, 11667, 12676
Local India Brand	10264, 10208, 11413
Local Malaysia Brand	10698
Lodos	11037
Loewe	10037, 10512, 10633, 11884
Logik	11037, 10698, 11687, 11865, 12241, 12486
Logix	10668
Longjiang	10264
Luma	11037
Lumatron	10037, 10668, 10264, 11937
Lumenio	10037
Lux May	10037

Luxor	10548, 11037, 10179, 10208, 11163, 12676
LXI	10047, 10156, 10178
<b>M</b> Madison	10037
MAG	11498, 11687
Magnavox	10051, 10030, 10171, 11454, 10706, 10036, 10179, 11365, 11455, 11506, 11866, 11867, 11944, 11963, 11990, 12372
Magnum	10037, 10714, 11556
Mandor	10264
Manesth	10037, 10264
Manhattan	10037, 10668, 11037
Marantz	10030, 11454, 10556, 10037
Mark	10037, 10714
Marks & Spencer	11770
Mascom	11556
Mastro	10053, 10706, 10698, 11556
Masuda	10037, 10264
Matsui	10556, 10037, 10714, 10195, 11037, 10036, 10208, 10443, 10744, 11666, 11667, 11916, 12007, 12486, 12676
Matsushita	10250, 10051, 10650
Matsuviana	10587
Maxdorf	11276
Maxent	10762
Maxess	12493
Maxim	11556
Meck	10698
Mediator	10556, 10037

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Medion	10556, 10037, 10714, 10668, 11037, 10698, 10512, 10808, 11163, 11248, 11556, 11585, 11667, 12676
Megatron	10178
MEI	11037
Meile	10264, 11910
Melectronic	10037, 10714, 10634, 10195, 10512, 10661, 11652
Memorex	10250, 10463, 10150, 10178, 11037, 10179, 11665, 11670, 11892
Memory	11983
Mercury	10037
Mermaid	10037
Metronic	10625
Metz	10668, 10195, 11037, 10587, 11163
MGA	10150, 10178, 10030
Micromaxx	10037, 10714, 10668, 11037, 10808, 11324
Microstar	10808
Midland	10047, 10017, 10051
Mikomi	10744, 11585, 11667
Minato	10037
Minerva	10195, 10108, 11248
Ministry Of Sound	11667
Minoka	10037
Mintek	11990
Mirai	11666
Miray	13309, 13321
Mitsai	11556

Mitsubishi	10250, 10093, 10180, 10150, 11250, 10178, 10030, 10556, 10037, 11037, 10036, 10108, 13542, 13514, 13500, 13330, 12313, 11797, 11150, 10512, 10474, 10179
Mivar	10609
Moree	10037
Morgan's	10037
Moserbaer	11585, 12449
Motorola	10093
MTC	10030, 10512
MTLogic	10714, 12104
Mudan	10051, 10264, 10208
Multitec	10037, 10668, 11037, 11556
Multitech	10180, 10037, 10264
Murphy	10474
Mx Onda	11498, 11687, 11983
Myrica	11666
Myryad	10556
<b>N</b> NAD	10156, 10178, 10037, 11156
Naiko	10037
Nakimura	10037
Nanbao	10264, 11910
Nansheng	10264
National	10051, 10508, 10208
Naxa	12104, 13382
NEC	10156, 10051, 10053, 10178, 10030, 10264, 10036, 10653, 10508, 10474, 10661, 11150, 11704, 11797, 12461
Neckermann	10556, 10037
NEI	10037, 11037

NEO	11324
Neoka	11826
Nesco	10179
Netsat	10037
NetTV	10762
Neufunk	10556, 10037, 10714
New Sonic	11826
New Tech	10556, 10037
Newave	10093, 10178, 10092, 11150
Nexus Electronics	12183
Nikai	11163
Nikkai	10037, 10264, 10036
Nikkei	10714
Nikko	10178, 10030, 10092
Nikon	11910
Nimbro	12104
Noblex	10264
Nokia	10180, 10548, 10179, 10208
Norcent	11365, 11589, 11745
Nordmende	10037, 10714, 10560, 10195, 11163, 11413, 11585, 11667, 12007
Normerel	10037
Nortek	10668
Norwood Micro	11286
Novatronic	10037
Novex	11523
Novita	11585
NTC	10092
<b>O</b> O.K.Line	11037, 11324
Oceanic	10548, 10208

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Odeon	10264
Odys	12513
Okano	10037, 10264
OKI	11585, 11667, 12125, 12676
Ölevia	11240, 11331, 11610
Omega	10264
Omni	10698
Onei	11667
Onida	10053, 10653, 11253, 12414
Onimax	10714
Onix	10698
Onn	11667, 11770, 12125
Onwa	10180
Onyx	11770
Opera	10037, 10714, 11770
Optimus	10250, 10650
Optoma	11348
Optonica	10093
Orbit	10037
Orion	10463, 10556, 10037, 10714, 11037, 10264, 10179, 10443, 10474, 11916, 12007, 12032, 12108
Orline	10037
Ormond	10668, 11037
Osaki	10556, 10037, 10264, 10474
Osio	10037
Osume	10037, 10036, 10474
Otic	11326, 11498, 11687, 11983
Otto Versand	10093, 10556, 10037, 10195, 10036, 10512

<b>P</b> Pacific	10556, 10714, 11037, 10443, 11324, 11916
Packard Bell	10092, 11314
Palladium	10556, 10037, 10714
Palsonic	10037, 10698, 10264, 10725, 11326, 12461
Panama	10037, 10264
Panasonic	10250, 10051, 10037, 10548, 10650, 10108, 10508, 12170, 11946, 11941, 11650, 11636, 11480, 11291, 11271, 11168, 10208
Panavision	10037
Panda	10051, 10706, 10698, 10264, 10508, 10208, 11910
PARK	12104
Penney	10047, 10156, 10051, 10178, 10030, 11347
Perdio	10037
Perfekt	10037
Petters	10037, 11523
Philco	10463, 10180, 10178, 10030, 10171, 11661, 10037, 13426, 13022, 12414, 11963, 11665, 11394, 11271, 10474, 10179, 10092
Philips	10017, 10000, 10051, 10178, 10030, 10171, 11454, 10556, 10037, 10108, 11756, 11866, 11867, 11887, 12227, 12372, 12374, 12800, 11744, 11506, 11455, 11394, 10810, 10639, 10512, 10474, 10092
Phocus	10714, 11652
Phoenix	10037
Phonola	10556, 10037
Pilot	10030, 10706

Pioneer	10037, 10698, 10512, 10679, 11260, 11457, 11636
Pionier	11556
Pixela	13496
Planar	11589
Plantron	10037, 10264
Playsonic	10037, 10714, 11652
Plustron	11770
Polaroid	10765, 11276, 11286, 11314, 11326, 11498, 11523, 11645, 11687, 11826, 12121, 12125
Polyvision	10889
Portland	11661, 10092, 10624
Power Acoustik	11865
Powerpoint	10037, 10698, 11770
Premier	10264
Prima	10264, 10474, 11749
Princess	11326
Prinston	11037
Prism	10051
Pro Vision	10556, 10037, 10714, 11324, 12197
Prodia	13496
Profilo	11556
Profitronic	10037
Proline	10037, 10625, 10634, 11037
Proscan	10047, 10030, 11447, 11347, 12147, 12183, 12256, 13577
Proscopro	10156
Prosonic	10037, 10714, 10668, 11163, 11314, 11324, 11523, 11585, 11667, 11770, 11865, 12125, 12197, 12676

AVR	CBL/SAT group	TV group	VCR/PVR group	BD/DVD group	Audio group
Protech	10037, 10668, 11037, 10264	Relisys	11585, 11645		10463, 10171, 10706, 10037, 10714, 10898, 11243, 11248, 11413, 11556, 11670, 11892, 13564
Proton	10178, 10030, 10474	Relon	11826	Sansui	
Proview	11498, 11687	Remotec	10250, 10093, 10171, 10037		
Pulsar	10017	Reoc	10714, 12197		10156, 10180, 11037, 10264, 10036, 10508, 13348, 12676, 12461, 11667, 11585, 11498, 11365, 11276, 11208, 11150, 11142, 10474, 10208
Pye	10556, 10037	Revox	10037, 10808	Sanyo	
<b>Q</b> Qingdao	10051, 10264, 10208	Rex	10264		
Quadro	11326	RFT	10037, 10264	Sanyuan	10093
Quasar	10250, 10051, 10650, 10474, 11291	Roadstar	10037, 10714, 10668, 11037, 10264, 11916	SBR	10556, 10037
Quelle	10037, 10668, 10195, 11037, 10512	Rolsen	12098	Sceptre	11360, 11599, 12337, 12506
Questa	10036	Rover	10036	Schaub Lorenz	10548, 10714, 11324, 11363, 11667, 12125, 12241, 12676
<b>R</b> R-Line	10037	Rowa	10037, 10698, 10264, 10587, 10898, 12042	Schneider	10556, 10037, 10714, 10668, 11037, 12676
Radiola	10556, 10037	Runco	10017, 10030	Schöntech	11037
Radiomarelli	10037	<b>S</b> Saba	10250, 10625, 10548, 10714, 10560	Scotch	10178
RadioShack	10047, 10180, 10178, 10030, 10037	Sagem	10618	Scott	10180, 10178, 10179, 11983
Radiotone	10037, 10668, 11037, 10264	Saisho	10264	Sears	10047, 10156, 10178, 10171, 10179
Rank Arena	10036	Saivod	10037, 10668, 11037, 11163, 11556	Seaway	10634
	10047, 10000, 10051, 10093, 10178, 10030, 11661, 11447, 11454, 10625, 10560, 10618, 12746, 12434, 12247, 12932, 12187, 13577, 11953, 11948, 11781, 11547, 11347, 10679, 10624, 10092, 10090	Sakura	11326	Seelver	11037
RCA		Salora	10548, 10208, 11556, 12125, 12197	SEG	10037, 10668, 11037, 10264, 10036, 10624, 11163, 11523, 12125
Realistic	10180, 10178, 10030	Sampo	10093, 10178, 10030, 10171, 10036, 10650, 10092, 10474, 10762, 10898, 13419	SEI	10037
Recco	10706		10156, 10093, 10812, 10702, 10178, 10030, 10556, 10037, 10264, 10587, 10618, 10650, 10179, 10208, 10474, 10092, 10090, 11150, 11619, 11632, 12042, 12051	Sei-Sinudyne	10037
Recor	10037	Samsung		Seiki	10178, 12964, 13559
Rectiligne	10037			Semivox	10463, 10180
Red	12032	Sanjian	10264	Semp	10156, 11743
Red Star	10037	Sanken	12042	Semp Toshiba	10156, 11743
Rediffusion	10548, 10036	Sansei	10092	Sencor	10714
Reflex	10037, 10668, 11037			Sens	11865
				Serie Dorada	10156, 10180, 10178, 10030

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Serino	10093
Shancha	10264
Shanghai	10264, 10208, 11910
Sharp	10093, 10053, 10030, 10036, 10650, 11193, 13101, 12810, 12676, 12360, 12214, 11659, 11423, 11393, 10818, 10474
Shen Ying	10092, 10179, 10474
Shencai	10264
Sheng Chia	10093, 10179, 10474, 11150
Shenyang	10264
Shinco	11990
Shinelco	12104
Shintoshi	10037
Shivaki	10178, 10037, 10443
Shorai	10179
Siam	10037
Siemens	10037, 10195
Siera	10556, 10037
Sigmac	13423
Silva	10037
Silva Schneider	10037, 11556, 12125, 12197
Silvano	10587
Silver	10036, 10179
SilverCrest	11037, 12676
Singer	11556
Sinudyne	10037
SKY	10037, 11745
Skygiant	10180
Skyworth	10037, 10698, 10264
Sliding	11324
SLX	10668

Soemtron	11298
Solavox	10037, 10548
Soniko	10037
Soniq	12493
Sonitron	10208
Sonneclair	10037
Sonoko	10037, 10264
Sonolor	10548, 10208
Sontec	10037
Sontech	11983
Sony	10000, 11505, 10036, 10810, 11300, 11551, 11625, 11651, 11825, 12568, 12571, 12736, 12747, 12778
Soundesign	10180, 10178, 10179
Soundwave	10037, 11037
Sowa	10156, 10051, 10178, 10036, 10092, 10474, 11150
Soyea	12042
Soyo	11826
Spectroniq	11498, 11687
Squareview	10171
SR Standard	10037, 11037
SSS	10180
Starlite	10180, 10037, 10264
Stern	10264
Strato	10037, 10264, 12032
Strong	11163
SunBriteTV	11610, 12337
Sungoo	11248
Sunny	10037
Sunstar	10037, 10264

Sunview	13265
Sunwood	10037
Superscan	10093, 10864, 11944
Supersonic	10208, 12104
SuperTech	10556, 10037
Supra	10178
Supreme	10000
Susumu	10474
SVA	10587, 11326, 11498, 11963, 12042
Svasa	10208
Swisstec	11745, 12104, 12106
Sylvania	10030, 10171, 10587, 11271, 11314, 11394, 11665, 11864, 11886, 11944, 11963
Symphonic	10180, 10171, 11394, 11944
Synco	10000, 10093, 10178, 10036, 10092, 10474, 11826
Syntax	11240, 11331, 11610
Sysline	10037
Tacico	10178, 10092, 10179, 10474, 11150
Tai Yi	11150
Talent	10178
Tandy	10093
Tashiko	10036, 10650, 10092, 11150
Tatung	10156, 10051, 10037, 10036, 10474, 11150, 11156, 11248, 11286, 11324, 11556, 11687, 11756, 11916
Taurus	12197
TCL	10706, 10698, 10898, 11916, 12414, 12434, 12449, 13183
TCM	10714, 10808

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Teac	10178, 10171, 10706, 10037, 10714, 10668, 11037, 10698, 10264, 10587, 10624, 10512, 10898, 11248, 11363, 11645, 11770, 11983, 12032, 12241
Tec	10037, 10474
Tech Line	10037, 10668, 11163
Technica	11037, 12106
Technics	10250, 10051, 10556, 10650
Technika	11667, 11865, 11983, 12032, 12106, 12125, 12197, 12676
TechniSat	10556
Technisson	10714, 11652
Techno	11585
Technol Ace	10179
Technosonic	10556, 10625, 11324, 11326, 12032
Techvision	12032
Techwood	10051, 11037, 11163, 11667, 12676
Tecnimagen	10556
Teco	10051, 10093, 10053, 10178, 10030, 10264, 10036, 10653, 10092, 10474, 10762, 11523, 11687, 11838
Tedelex	10208
Teknika	10180, 10150, 10092, 10179
TELE System	11585, 12125
Telecor	10037
Telefunken	10702, 10037, 10625, 10714, 10560, 10698, 10587, 11243, 11326, 11556, 11585, 11667, 12676
Telefusion	10037
Telegazi	10037, 10264

Telemeister	10037
Telesonic	10037
Telestar	10556, 10037
Teletech	10037, 10668, 11037
Teleton	10036
Television	10037
Tempest	10264
Tennessee	10037
Tensai	10037, 11037
Tera	10030, 10092, 10474
Tesla	10556, 10037, 10714, 11037, 11652
Tevion	10556, 10037, 10714, 10668, 11037, 12241, 12032, 11687, 11667, 11645, 11585, 11556, 11498, 11298, 11248, 10808, 10767
Thomson	11447, 10037, 10625, 10560
Thorn	10037, 10036, 10512
Tiane	10093
TMK	10178
TML	11756
TNCi	10017
Tobo	10264
Tokai	10037, 10668, 11037
Tokaido	11037
Tongguang	10264
Tongtel	10587
Tophouse	10180
Topline	10668, 11037

Toshiba	10156, 10093, 11265, 11256, 10195, 11037, 10264, 10036, 10618, 10650, 10508, 11945, 12006, 12311, 12676, 12724, 13105, 13492, 13503, 13504, 13570, 11916, 11743, 11704, 11656, 11652, 11556, 11524, 11508, 11156, 11150, 10767
Tosumi	11770
Toyoda	10264
Trakton	10264
TRANS-continents	10556, 10037, 10668, 11037
Transonic	10037, 10698, 10264, 10587, 10512, 11326, 11363
Triad	10556
Trio	11248, 11498, 11687
Tristar	10264
Triumph	10556, 10037
TruTech	11665
Tuntex	10030, 10092, 10474
TVS	10463
TVTEXT 95	10556
Uher	10037
Ultravox	10037
UMC	11745, 12106
Unic Line	10037
Uniden	12122
United	10556, 10037, 10714, 11037, 10587, 11163, 11523, 11652, 11770, 11916, 11983, 12125
Universal	10037, 10714
Universum	10037, 10668, 10195, 11037, 10264, 10036, 10618, 10474, 10512, 10808, 11163

U



## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

V	Univox	10037
	US Logic	11286
	V7 Videoseven	11666
	Vector Research	10030
	Venturer	11865
	Venus	11326
	Vestel	10037, 10668, 11037, 11163, 11585, 11667
	Vexa	10037
	Victor	10250, 10053, 10036, 10650, 10653, 11428
	Videocon	10037, 10508
	VideoSystem	10037
	Vidtech	10178, 10036
	Viewsonic	10864, 10885, 11365, 11564, 11578, 11627, 11742, 11745, 12014, 12049, 12087, 12277, 13247
	Viore	11684, 12104, 12352, 13094, 13118, 13382
	Vision	10037, 10264, 10474, 11826
	Vistron	11363
	Visual Innovations	12106
	Vito	12376
	Vivax	11326
	Vizio	10864, 10885, 11756, 11758, 12116, 12512, 12757, 13758
	Vortec	10037
	Voxson	10178, 10037, 12197
	VU	11365, 12098, 12449
W	Walker	11667
	Waltham	10037, 10668, 11037, 10443
	Wansa	12098

	Wards	10047, 10017, 10000, 10156, 10051, 10180, 10178, 10030, 10179, 11156, 11347
	Warumaia	10661
	Watson	10037, 10714, 10668, 11037
	Waycon	10156
	Wega	10037, 10036
	Welltech	10714, 11652
	Weltstar	11037
	Westinghouse	10885, 10889, 11282, 11300, 11577, 11712, 11826, 13470, 13579
	Wharfedale	10556, 10037, 11324, 11556, 11667, 11983
	White Westinghouse	10463, 11661, 10037, 10624
	Wilson	10556
	Windsor	10668, 11037
	Windy Sam	10556
	Wintel	10714
	World-of-Vision	11298
	Wyse	11365
X	Xenius	10634, 10661
	Xi-En	11770
	Xiahua	10698, 10264
	Xiangyang	10264
	Xihu	10264
	Xinghai	10264
	Xinrisong	11910
	Xiron	11983
	XLogic	10698
	Xoceco	10725, 12121, 13022
	Xomax	11770

	Xoro	11243
	Xrypton	10037
	Xuelian	11910
Y	Yamaha	10030, 10650, 11576
	Yamishi	10037
	Yapshe	10250
	Yokan	10037
	Yoko	10037, 10264
	Yongbao	11910
	Yousida	11910
	YU-MA-TU	10037
	Zenith	10047, 10017, 10000, 10463, 11265, 10178, 10030, 11145, 11661, 10092, 10624, 11365, 11423, 12358, 12362, 12731
	Zepto	11585
	Zinwell	12116
	Zonda	10698

## TV/DVD Combination

A	Acoustic Solutions	11865
	AEG	12197
	Akai	11675, 11865, 12676
	Akura	11770, 11983
	Alba	10587, 11865, 12104, 12676
	Audiosonic	11983, 12104
	Audiovox	11865, 11937, 12513
	Axion	11937
B	Belson	12241
	Black Diamond	11037
	Blue Sky	11037, 12153

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Bush	11037, 10698, 10587, 11556, 11983, 12104, 12676
<b>C</b> cello	11770
Centrum	11037
Changhong	11243
Coby	12315, 12340, 12343, 12344, 12347, 12350
Coradir	12844
Crown	11037
Curtis	12466, 12855
<b>D</b> D-Vision	12197
Denver	10587, 11770, 12197
Dew	11770
DMTech	11937
Dual	11037, 12241
Dynaconnective	12811
Dynex	11810, 12049, 12184
<b>E</b> Easy Living	12104
Electrohome	11670
Elfunk	11037
Emerson	11394, 11864, 11886, 11963
ESA	11963
Essentials	12486
<b>F</b> Ferguson	11037
Finlux	11556
Funai	11963
<b>G</b> GFM	11963
Gold	11770
Goodmans	11037, 11687, 11983, 12676
<b>H</b> Haier	11748, 12309
Hantarex	12197

Hikona	11983
Hitachi	11037, 11667, 12207, 12676, 13317, 13456
Hyundai	11770
<b>I</b> iLo	11990
Initial	11990
Insignia	11963, 12049, 12417
iSymphony	13094
<b>J</b> J:COM	12811
JVC	11774, 12271
<b>L</b> Lenco	10587, 11983
LG	11423
Linsar	12676
Logik	11037, 11687, 11865, 12486
Luxor	11037
<b>M</b> Magnavox	11866, 11944, 11963, 11990, 12372
Marks & Spencer	11770
Matsui	11037, 12486, 12676
Medion	12676
Memorex	11670
Memory	11983
Mintek	11990
Mitsubishi	13330
MTLogic	12104
Mx Onda	11983
<b>N</b> Naxa	12104, 13382
Nimbro	12104
<b>O</b> Onn	11770
Onyx	11770
Opera	11770

Otic	11983
<b>P</b> Panasonic	11941, 12170
Philips	11454, 10556, 11394, 12372
Plustron	11770
Polaroid	11523
Power Acoustik	11865
Powerpoint	10698, 11770
Proscan	12256
Prosonic	11770, 11865, 12197, 12676
<b>R</b> RCA	11447, 11948, 12187, 12746, 12932
<b>S</b> Salora	12197
Samsung	12051
Sansui	11670, 13564
Sanyo	12676
Scott	11983
SEG	11037
Sens	11865
Sharp	10818, 12360, 12676
Shinco	11990
Shinelco	12104
Soniq	12493
Sontech	11983
Sony	12778
Supersonic	12104
Swisstec	12104
Sylvania	10171, 11394, 11864, 11886, 11963
<b>T</b> Taurus	12197
TCL	11916
Teac	10698, 10587, 11770, 11983, 12241

## AVR

Technica	11037
Technika	11865, 11983, 12106
Telefunken	10698
Teletech	11037
Tevion	12241
Thomson	10625
Toshiba	11256, 11524, 12006, 13105, 13492
Tosumi	11770
Trasonic	10587
<b>U</b> UMC	12106
United	11037, 10587, 11770, 11983
<b>V</b> Venturer	11865
Vestel	11037
Viewsonic	10864, 12049
Viore	12104, 12352, 13094, 13118, 13382
<b>W</b> Weltstar	11037
Westinghouse	11300, 11712
Wharfedale	11983
<b>X</b> Xiron	11983
Xomax	11770

## TV/VCR Combination

<b>A</b> Aiwa	11910, 11916
America Action	10180
Amstrad	10171
Audiovox	10180
<b>B</b> Blue Sky	10624, 11916
Broksonic	10463
Bush	11916

## CBL/SAT group

## TV group

<b>C</b> Curtis Mathes	10051
<b>D</b> Daewoo	10624
Dantax	11916
<b>E</b> Emerson	10463, 10624
<b>F</b> Ferguson	10625
Fidelity	10171
Firstline	10624
<b>G</b> GE	10047, 10051, 10093
GoldStar	10037
Goodmans	10624, 11916
Gradiente	11804
Grandin	10624
Grundig	10556, 10037, 10195, 11916
<b>H</b> Hinari	10036, 10179
<b>I</b> Internal	10624
<b>J</b> JVC	11253
<b>L</b> LG	10178
<b>M</b> Matsui	11916
Memorex	10250
Mitsubishi	10093, 10556, 11150
Orion	10463, 11916
<b>P</b> Pacific	11916
Panasonic	10250, 10051
Penney	10051
Philips	10556, 10037
Portland	10624
<b>Q</b> Quasar	10250, 10051
<b>R</b> Radiola	10556
RCA	10047, 10051, 10093
Roadstar	11916
<b>S</b> Saba	10625

## VCR/PVR group

## BD/DVD group

## Audio group

Sansui	10463
Schneider	10556, 10037
SEG	10624
Sharp	10093
Siemens	10037
Sony	10000, 11505
<b>T</b> Tatung	11916
Teac	10178, 10171, 10624
Technics	10556
Thomson	10625
Toshiba	11916, 11945, 12006
<b>U</b> United	11916
<b>W</b> White Westinghouse	10624
<b>Z</b> Zenith	10017

## TV/VCR/DVD Combination

<b>E</b> Emerson	11944, 11963
ESA	11944
<b>I</b> Insignia	11963
<b>M</b> Magnavox	11944, 11963
<b>P</b> Panasonic	11941, 11946
<b>R</b> RCA	11953
<b>S</b> Superscan	11944
Sylvania	11944
Symphonic	11944
<b>T</b> Toshiba	11945

## VCR/PVR group

### VCR

<b>A</b>	ABS	21972	ASA	20037, 20081	Carrefour	20045	
	Accent	20072	Asha	20240	Carver	20081	
	Accurian	20000	Asuka	20037, 20081, 20000, 20072	Casio	20000	
	Admiral	20048, 20209	Audiolab	20081	Cathay	20278	
	Adventura	20000	Audiosonic	20278	CCE	20072, 20278	
	Adyson	20072	Audiovox	20037, 20278	Centrum	20593, 21593	
	AEG	21593	AVP	20000	CGE	20000, 20041	
	Aiko	20278	Awa	20037, 20043, 20278, 20642, 20320	Changhong	20048, 20081	
	Aim	20278, 20642	<b>B</b>	Baird	20000, 20104, 20041, 20278	Cimline	20209, 20072
	Aiwa	20037, 20032, 20000, 20209, 20041, 20742, 21137		Basic Line	20104, 20072, 20278	Cineral	20278
	Akai	20037, 20240, 20000, 20041, 20642		Beaumarck	20240	CineVision	21137
	Akiba	20072		Bell & Howell	20104	Citizen	20037, 20278
	Akura	20041, 20072		Bestar	20278	Clatronic	20000, 20072, 21593
	Alba	20081, 20000, 20209, 20072, 20278		Black Diamond	20642	Colt	20072
	Alienware	21972		Black Panther	20278	Condor	20278
	Allegro	20039, 21137		Blaupunkt	20162, 20081	Craig	20037, 20047, 20240, 20072
	Allorgan	20240		Blue Sky	20037, 20209, 20072, 20278, 20642, 20742, 21137	Crosley	20081, 20000
	Allstar	20081		Bondstec	20072	Crown	20037, 20072, 20278
	America Action	20278		Brandt	20041, 20320	Curtis Mathes	20060, 20035, 20162, 20240, 20041, 20278
	American High	20035		Brandt Electronique	20041	Cybernex	20240
	Amstrad	20000, 20072, 20278		Brinkmann	20209	CyberPower	21972
	Anam	20162, 20037, 20240, 20278, 21562		Broksonic	20121, 20209, 20742	Cyrus	20081
	Anitech	20072		Bush	20081, 20000, 20209, 20072, 20278, 20642, 20742	<b>D</b>	
	Ansonic	20000	<b>C</b>	Calix	20037	Daewoo	20045, 20104, 20209, 20278, 20642, 21137
	Aristona	20081		Canon	20035	Dansai	20072, 20278
				Carena	20081, 20209	Dantax	20742
						Daytron	20278
						De Graaf	20048, 20081, 20042, 20104

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Decca	20081, 20000, 20067, 20209, 20041
Deitron	20278
Dell	21972
Denko	20072
Denon	20042
Diamant	20037
Digitor	20642
DirecTV	20739
Domland	20209
DSE	20000, 20642, 21593
Dual	20081, 20000, 20041, 20278
Dumont	20081, 20000, 20104
Durabrand	20039, 20642, 20593, 21593
Dynatech	20000
<b>E</b> E.S.C.	20240, 20278
Elbe	20278
Elcatech	20072
Electrohome	20037, 20043
Electroponic	20037
Eiin	20240
Elsay	20072
Elta	20072, 20278
Emerex	20032
Emerson	20035, 20037, 20240, 20045, 20000, 20121, 20043, 20209, 20072, 20278, 20593, 21593
ESA	21137
EuroLine	21593
<b>F</b> Ferguson	20000, 20041, 20278, 20320, 20742
Fidelity	20240, 20000, 20072

Finlandia	20037, 20048, 20081, 20000, 20042, 20104, 20043
Finlux	20081, 20000, 20042, 20104
Firstline	20037, 20045, 20042, 20043, 20209, 20072, 20278, 21137
Fisher	20047, 20104
Flint	20209
Frontech	20072
Fuji	20035, 20033
Fujitsu	20045, 20000
Fujitsu General	20037
Fujitsu Siemens	21972
Funai	20000, 20593, 21593
<b>G</b> Galaxi	20000
Galaxis	20278
Garrard	20000
Gateway	21972
GE	20060, 20035, 20048, 20240, 20320, 20202
GEC	20081
General	20045
Genexxa	20104
GFM	21593
Go Video	20240, 21137
GoldHand	20072
GoldStar	20037, 20000, 20209, 21137
Goodmans	20037, 20081, 20240, 20000, 20209, 20072, 20278, 20642, 20742
GPX	20037
Gradiente	20000, 21137
Graetz	20240, 20104, 20041

Granada	20037, 20048, 20081, 20240, 20000, 20042, 20104
Grandin	20037, 20000, 20209, 20072, 20278, 20742
Grundig	20081, 20072, 20320, 20742
<b>H</b> Hanseatic	20037, 20081, 20209
Haojie	20240
Harley Davidson	20000
Harman/Kardon	20081
Harwood	20072
HCM	20072
Hewlett Packard	21972
HI-Q	20047
Hinari	20240, 20209, 20041, 20072, 20278
Hisawa	20209
Hischito	20045
Hitachi	20037, 20081, 20240, 20000, 20042, 20041, 20593
Höher	20278, 20642
Hornophon	20081
Howard Computers	21972
Hughes Network Systems	20042
Humax	20739
Hush	21972
Hypson	20037, 20000, 20209, 20072, 20278
<b>I</b> iBUYPOWER	21972
Imperial	20000
Ingersoll	20240, 20209
Inno Hit	20072

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Instant Replay	20035
Interbuy	20037, 20072
Interfunk	20081, 20104
Internal	20278
International	20037, 20278, 20642
Intervision	20037, 20000, 20209, 20278
Irradio	20037, 20081, 20072, 21137
ITT	20240, 20104, 20041
ITV	20037, 20278
<b>J</b> JBL	20278
Jensen	20041
JMB	20209, 20742
Joyce	20000
JVC	20081, 20045, 20067, 20041
<b>K</b> Kaisui	20072
Kambrook	20037
Karcher	20081, 20278, 20642
KEC	20037, 20278
Kendo	20037, 20209, 20072, 20278, 20642
Kenwood	20067, 20041
KIC	20000
Kimari	20047
KLH	20072
Kneissel	20037, 20209, 20278
Kodak	20035, 20037
Kolin	20043, 20041
Kolster	20209
Korpel	20072
Kuba Electronic	20047
Kyoto	20072

<b>L</b> Lenco	20278
Leyco	20072
LG	20037, 20045, 20000, 20042, 20209, 20278, 21137
Lifetec	20209
Linksys	21972
Lloyd's	20000
Loewe	21062, 20162, 20037, 20081, 21562
Logik	20240, 20209, 20072
Lumatron	20593, 21137
Lunatron	21137
Lux May	20072
Luxor	20048, 20047, 20104, 20043, 20072
LXI	20037
<b>M</b> Magnasonic	20278, 20593
Magnavox	20035, 20039, 20081, 20000, 20642, 20593, 21593
Magnin	20240
Magnum	20642
Manesth	20081, 20045, 20209, 20072
Marantz	20035, 20081, 20209
Mark	20000, 20278
Marta	20037
Mascom	20642
Mastec	20642
Master's	20278
Matsui	20037, 20240, 20209, 20278, 20742
Matsushita	20035, 20162
Media Center PC	21972

Mediator	20081
Medion	20209, 20642
MEI	20035
Melectronic	20037, 20000
Memorex	20035, 20162, 20037, 20048, 20039, 20047, 20240, 20000, 20104, 20209
Memphis	20072
Metronic	20081
Metz	21062, 20162, 20037, 20081, 21562, 20836, 20837
MGA	20240, 20043
MGN Technology	20240
Micromaxx	20209
Microsoft	21972
Migros	20000
Mind	21972
Minolta	20042
Mitsubishi	20048, 20081, 20000, 20067, 20043, 20041, 20642
Motorola	20035, 20048
MTC	20240, 20000
Multitec	20037
Multitech	20000, 20072
Murphy	20000
Myryad	20081
<b>N</b> NAD	20104
Naiko	20642
NAP	20039
Nebula Electronics	20033

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

NEC	20035, 20037, 20048, 20104, 20067, 20041, 20278, 21137
Neckermann	20081, 20041
Nesco	20000, 20072
Neufunk	20209, 21137
Newave	20037
Nikkai	20072, 20278
Nikko	20037
Niveus Media	21972
Noblex	20240
Nokia	20048, 20081, 20240, 20042, 20104, 20041, 20278
Nordmende	20067, 20041, 20642, 20320
Northgate	21972
Nu-Tec	20209
<b>O</b> Oceanic	20048, 20081, 20000, 20104, 20041, 20320
Okano	20209, 20072, 20278
Olympus	20035
Onimax	20642
Optimus	21062, 20162, 20037, 20048, 20104, 20593
Orbit	20072
Orion	20121, 20209, 20742
Orson	20000
Osaki	20037, 20000, 20072
Osume	20072
Otake	20209
Otto Versand	20081
<b>P</b> Pacific	20000, 20642, 20742
Packard Bell	21972
Palladium	20037, 20209, 20041, 20072

Palsonic	20000, 20072, 20642
Panasonic	21062, 20035, 20162, 21562, 20616, 20836, 20837
Pathe Cinema	20043
Pathe Marconi	20041
Penney	20035, 20037, 20240, 20042
Pentax	20042
Perdio	20000, 20209
Philco	20035, 20000, 20209, 20072
Philips	20035, 20081, 20000, 20593, 20739
Phoenix	20278
Phonola	20081
Pilot	20037
Pioneer	20162, 20081, 20042, 20067
Polk Audio	20081
Portland	20278
Presidian	21593
Prinz	20000
Pro Vision	20278
Profitronic	20081, 20240
Proline	20000, 20278, 20642, 20320
Proscan	20060, 20202
Proscopro	20278
Prosonic	20209, 20278
Protech	20081, 20072
Pulsar	20039
Pye	20081, 20000
<b>Q</b> Qisheng	20060
Quasar	20035, 20162, 20278
Quelle	20081

<b>R</b> Radialva	20037, 20048, 20081, 20072
Radiola	20081
Radionette	20037, 21137
RadioShack	20037, 20000
Radix	20037
Randex	20037
Rank	20041
Rank Arena	20041
RCA	20060, 20035, 20048, 20240, 20000, 20042, 20320, 20202
Realistic	20035, 20037, 20048, 20047, 20000, 20104
ReplayTV	20616
Rex	20041
RFT	20072
Ricavision	21972
Rio	21137
Roadstar	20037, 20081, 20240, 20072, 20278, 20742
Royal	20072
Runco	20039
<b>S</b> Saba	20041, 20278, 20320
Saisho	20209
Salora	20104, 20043
Sampo	20037, 20048
Samsung	20240, 20045, 20742
Sanky	20048, 20039
Sansei	20048
Sansui	20000, 20067, 20209, 20041, 20072
Sanyo	20048, 20047, 20240, 20104, 20067, 21137

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Saville	20240, 20278
SBR	20081
ScanSonic	20240
Sceptre	20104
Schaub Lorenz	20000, 20104, 20041
Schneider	20037, 20081, 20240, 20000, 20042, 20072, 20278, 20642, 21137
Scott	20045, 20121, 20043, 20593
Sears	20035, 20037, 20047, 20000, 20042, 20104
Seaway	20278
SEG	20081, 20240, 20072, 20278, 20642, 20593
SEI	20081
Sei-Sinudyne	20081
Seleco	20037, 20041
Semivox	20045, 20209
Semp	20045
Semp Toshiba	20045
Sentra	20072
Setron	20072
Sharp	20037, 20048, 20209, 20848, 21137
Shinco	20000
Shintom	20104, 20072
Shivaki	20037
Shogun	20240
Siemens	20037, 20081, 20104, 20320
Siera	20081
Signature	20035
Silva	20037

Silva Schneider	21137
Silver	20278
SilverCrest	20642
Singer	20045, 20072
Sinudyne	20081, 20209
Sonic Blue	20616, 21137
Sonneclair	20072
Sonolor	20048
Sontec	20037, 20278
Sonwa	20642
Sony	20035, 20032, 20033, 20000, 21032, 21972
Soundwave	20037, 20209
SR Standard	20278
Ssangyong	20072
Stack 9	21972
Stern	20278
STS	20042
Sunkai	20209, 20278
Sunstar	20000
Suntronic	20000
Sunwood	20072
Supra	20037, 20278
Sylvania	20035, 20081, 20000, 20043, 20593, 21593
Symphonic	20000, 20593, 21593
Systemax	21972
T+A	20162
Tagar Systems	21972
Taisho	20209
Tandberg	20278

Tandy	20000, 20104
Tashiko	20037, 20048, 20081, 20240, 20000
Tatung	20048, 20081, 20045, 20000, 20067, 20043, 20209, 20041, 20742
Teac	20037, 20000, 20041, 20072, 20278, 20642, 20593, 21593
Tec	20072
Tech Line	20072
Technics	20035, 20162, 20081
Teco	20035, 20037, 20048, 20041
Tedelex	20037, 20209, 20642
Teknika	20035, 20037, 20000
Teleavia	20041
Telefunken	20209, 20041, 20278, 20642, 20320, 20593
Telestar	20037
Teletech	20000, 20072, 20278
Tenosal	20072
Tensai	20037, 20000, 20072, 20278
Tesla	20081
Tevion	20209, 20642
Texet	20278
Thomas	20000
Thomson	20060, 20067, 20041, 20278, 20320, 20202
Thorn	20037, 20104, 20041
TiVo	20739
TMK	20240
Tokai	20037, 20104, 20041, 20072



## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

<b>T</b>	Toshiba	20081, 20045, 20042, 20067, 20043, 20209, 20041, 20742, 21972
	Totevision	20037, 20240
	Touch	21972
	Towada	20072
	Toyoda	20278
	Tradex	20081
	Triad	20278
<b>U</b>	Uher	20240
	Ultravox	20278
	Unitech	20240
	United	20742, 21593
	Universum	20037, 20081, 20240, 20000, 20104, 20209, 21137
<b>V</b>	Vector	20045
	VIA Technologies	21972
	Victor	20067, 20041
	Video Concepts	20045
	Video Technic	20000
	Videomagic	20037
	Videosonic	20240
	Viewsonic	21972
	Villain	20000
	Voodoo	21972
<b>W</b>	Wards	20060, 20035, 20048, 20039, 20047, 20081, 20033, 20240, 20045, 20000, 20042, 20072
	Watson	20081, 20642
	Weltblick	20037
	Wharfedale	20642, 20593

	White Westinghouse	20209, 20072, 20278
<b>X</b>	XR-1000	20035, 20000, 20072
<b>Y</b>	Yamaha	20041
	Yamishi	20072, 20278
	Yokan	20072
	Yoko	20037, 20240, 20072
	Yoshita	20072
<b>Z</b>	Zenith	20037, 20039, 20033, 20000, 20209, 21137
	ZT Group	21972
	ZX	20209

## PVR

<b>A</b>	ABS	21972
	Alienware	21972
<b>C</b>	CyberPower	21972
<b>D</b>	Dell	21972
	DirecTV	20739
<b>G</b>	Gateway	21972
<b>H</b>	Hewlett Packard	21972
	Howard Computers	21972
	Humax	20739
	Hush	21972
<b>I</b>	iBUYPOWER	21972
<b>L</b>	Linksys	21972
<b>M</b>	Media Center PC	21972
	Microsoft	21972
	Mind	21972
<b>N</b>	Niveus Media	21972
	Northgate	21972

<b>P</b>	Panasonic	20616
	Philips	20739
<b>R</b>	ReplayTV	20616
<b>S</b>	Sonic Blue	20616
	Sony	21972
	Stack 9	21972
	Systemax	21972
<b>T</b>	Tagar Systems	21972
	TiVo	20739
	Toshiba	21972
	Touch	21972
<b>V</b>	Viewsonic	21972
	Voodoo	21972
<b>Z</b>	ZT Group	21972

## SAT/PVR Combination

<b>D</b>	DirecTV	20739
----------	---------	-------

## TV/VCR Combination

<b>A</b>	Aiwa	20000, 20742, 21137
	America Action	20278
	Amstrad	20000
	Audiovox	20278
<b>B</b>	Bestar	20278
	Blue Sky	20278, 20742
	Broksonic	20742
	Bush	20742
<b>C</b>	Citizen	20278
	Colt	20072
	Curtis Mathes	20035

AVR		CBL/SAT group		TV group		VCR/PVR group		BD/DVD group		Audio group	
<b>D</b>	Daewoo	20278			Orion	20742			<b>W</b>	White Westinghouse	20278
	Dantax	20742			<b>P</b>	Pacific	20742		<b>Z</b>	Zenith	20000
<b>E</b>	Emerson	20278, 20593				Palsonic	20000				
<b>F</b>	Ferguson	20000, 20278, 20742				Panasonic	20035, 20162				
	Fidelity	20000				Penney	20035, 20037, 20240				
	Firstline	20278				Philips	20081				
	Funai	20000, 20593			<b>Q</b>	Quasar	20035, 20162				
<b>G</b>	GE	20060, 20035, 20048, 20240			<b>R</b>	Radiola	20081				
	GoldStar	20037				RadioShack	20000				
	Goodmans	20278, 20742				RCA	20060, 20035, 20048, 20240				
	Gradiente	21137				Roadstar	20742				
	Grandin	20278, 20742			<b>S</b>	Saba	20320				
	Grundig	20081, 20742				Samsung	20240, 20742				
<b>H</b>	Harley Davidson	20000				Sansui	20000				
	Hitachi	20000, 20593				Sanyo	20240				
	Hypson	20037				Schneider	20081, 20000				
<b>I</b>	Internal	20278				Sears	20037, 20000				
<b>J</b>	JBL	20278				Sharp	20037, 20048				
<b>K</b>	Kambrook	20037				Shivaki	20037				
	Kneissel	20278				Siemens	20081				
<b>L</b>	LG	20037				Sony	20032, 20000				
	Lloyd's	20000				Sylvania	20081, 20593				
	Loewe	20037				Symphonic	20000, 20593				
<b>M</b>	Magnasonic	20278, 20593			<b>T</b>	Tatung	20742				
	Magnavox	20081, 20000, 20593				Teac	20037, 20000, 20642, 20593				
	Magnin	20240				Technics	20081				
	Matsui	20742				Telefunken	20278				
	Memorex	20162, 20037				Thomas	20000				
	MGA	20240				Thomson	20278				
	Mitsubishi	20048, 20081, 20043				Toshiba	20742				
<b>O</b>	Optimus	20162, 20593			<b>U</b>	United	20742				

## BD/DVD group

### DVD

<b>3</b>	3D LAB	30539
<b>A</b>	Accurian	30675
	Acoustic Solutions	30730, 30713, 32082
	AEG	30770, 30790, 30675, 31233, 32173
	Afreey	30698
	Aim	30672
	Airis	30672, 31107
	Aiwa	30533, 30641
	Akai	30770, 30695, 30790, 30675, 30884, 31233
	Akura	31233, 31383
	Alba	30672, 30539, 30717, 30695, 30730, 30713, 30884
	Alco	30790
	Amitech	30770, 32187
	Amstrad	30770, 30790, 30713, 32139
	AMW	30872
	Ansonic	30831
	Apex Digital	30672, 30717, 30796, 31061
	Aristona	30539, 30646
	Arrgo	31023
	ASDA	32213
	Audio Authority	32555
	Audiosonic	31383
	Audiovox	30717, 30790
	Audioworld	30790
	Audix	30713

	Autovox	30713
	AVideo	32173
	Awa	30730, 30872, 32587
	Axil	32139
	Axion	30730
<b>B</b>	Basic Line	30713
	Bel Canto Design	31571
	Belson	32139
	Berthen	31643
	Best Buy	32139
	Black Diamond	30713, 30884
	Blaupunkt	30717
	Blu:sens	31233
	Blue Parade	30571
	Blue Sky	30672, 30651, 30695, 30790, 30713, 30884, 32623
	Brainwave	30770
	Brandt	30503, 30651, 30551
	Broksonic	30695
	Bush	30672, 30717, 30730, 30831, 30713, 30884, 31383
	Byd:sign	30872
<b>C</b>	California Audio Labs	30490
	CCE	30730
	Centrex	30672
	Centrum	30675, 30713
	Changhong	30627, 31061
	Cinea	30831

	Cineral	30730
	Cinetec	30713, 30872
	Citizen	30695
	CJ Digital	31643, 32173
	Classic	30730
	Clatronic	30672, 30675, 31233
	Clayton	30713
	CMX	31643
	Coby	30730, 31107, 31628, 32494
	Codex	31233
	Compacks	31107
	Conia	30672
	Contel	32331
	Continental Edison	30831, 30872
	Craig	30831
	Crown	30770, 30713
	Cybercom	30831
	CyberHome	31023
	Cytron	30651
<b>D</b>	Daenyx	30872
	Daewoo	30770, 30872, 32187
	Dansai	30770
	Dantax	30539, 30790, 30713
	Datsun	31233
	Daytek	30872
	Dayton Audio	30872
	DCE	30831
	Decca	30770

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

Denon	30490, 31634, 32258, 32748, 33698	Emerson	30675, 32213	Henss	30713
Denver	30672, 31107	Encore	30698	Hikona	31383
Dgtec	30672	EuroLine	30675, 31233, 31643	Hitachi	30573, 30664, 30695, 30713, 30884
Diamond	30651, 30790	<b>F</b> Fenner	30651	Hitech	33523
Dicra	32173	Ferguson	30651, 30695, 30713, 30884	Hiteker	30672
Digihome	30713	Finlux	30672, 30741, 30770	Höher	30651, 30831, 30713, 31643, 32173
DigiLogic	30713	Firstline	30713	Home Electronics	30770, 30730
digired	30717	Funai	30695, 30675	Home Tech Industries	31107, 31643
Digital	32173	<b>G</b> G-Hanz	32213	Humax	30646
DigitalMax	31738	G-HanzS	32213	HYD	31233
Digitor	30651	GE	30522, 30717	Hyundai	31061
Digitrex	30672	GFM	30675	Ilekei	31107
DiK	30831	Go Video	30744, 30741, 31044, 31075	Ingersoll	31023
Disney	30831, 30675, 31270	GoldStar	30741	Initial	30717
DK Digital	30831, 31643, 32095	Goodmans	30651, 30730, 30790, 30713, 30884, 31383	Inno Hit	30713
DMTech	32173, 32187	GoWell	31643	Insignia	30741, 30675, 32095, 32428, 32596
Dragon	30831	GPX	30741	Integra	30571, 30627, 31634, 31769, 32147
DSE	30675, 32095	Gradiente	30651	Irradio	30646, 31233
Dual	30651, 30730, 30831, 30790, 30713, 30884, 31023	Gran Prix	30831	ISP	30695
Durabrand	30831, 30675, 30713, 31023	Grandin	30713, 31233, 32173	it's	30717
DVS	30672	Greenhill	30717	ITT	31233
Dynex	32596	Grundig	30539, 30651, 30551, 30695, 30790, 30713, 31643	JDB	30730
<b>E</b> E:max	30770, 31233, 31643	Grunkel	30770, 30831, 30790	JMB	30695
ECC	30730	GVG	30770	JNC	30672
Elfunk	30713, 30884	<b>H</b> H & B	30713, 31233, 32173	JVC	30503, 30539, 30623, 30867, 31164, 31602, 32365, 32855
Elin	30770	Hanseatic	30741, 30790	jWin	30672
Elite	32854	Harman/Kardon	31229, 32927		
Elta	30672, 30770, 31233, 31643, 32173	HE	30730		
Eltax	31233	Hello Kitty	30831		

AVR		CBL/SAT group		TV group		VCR/PVR group		BD/DVD group		Audio group		
<b>K</b>	Kansai	31107		Magnavox	30503, 30539, 30646, 30675, 30713, 31354, 31506			Mizuda	30770			
	Kansas Technologies	31233		Magnum	31382			Mustek	30730			
	Kawasaki	30790		Majestic	31107			Muvid	31643, 32173			
	Kendo	30672, 30831, 30713		Manhattan	30713			Mx Onda	30651, 31383			
	Kennex	30770, 30713		Marantz	30539, 31627, 32414			Mystral	30831			
	Kenwood	30490, 30534		Mark	30713			<b>N</b> NAD	30741			
	KeyPlug	31643		Marquant	30770, 31628			Naiko	30770			
	Kiuro	30770		Matsui	30672, 30651, 30695, 30713, 30884			NEC	30741, 30785, 31602			
	King D'Home	30796		Maxim	30713, 30872			Neom	31643			
	King Vision	31643		MBO	30730			Nesa	30717			
	KLH	30717, 30790		McIntosh	31533			Nevir	30672, 30770, 30831			
	Koss	30651		MDS	30713			Nexius	30790			
	KXD	31107		Mecotek	30770			Noblex	31233			
	<b>L</b>	Lazer	32173		Medion	30651, 30630, 30741, 30831, 31107, 31270			Norcent	30872, 31107		
		Leiker	30872		MEI	30790			Nordmende	30831		
		Lenco	30651, 30770, 30713, 31383		Memorex	30695, 30831, 31270, 32213, 32331, 33153			Nortek	31643, 32173		
		Lexicon	32545		Memory	31383			<b>O</b> Ölevia	32331		
LG		30741, 30790, 31233, 31602		Metz	30571, 30713			Olidata	30672			
Lifetec		30651, 30831		Micromaxx	30695			Omni	30698			
LiteOn		31738		Micromedia	30503, 30539			One For All	32555			
LM		31643		Micromedia	30503, 30539			Onkyo	30503, 30627, 31627, 31769, 32147, 32562			
Lodos		30713, 30884		Micromedia	30503, 30539			Oppo	32545			
Loewe		30539, 30741		Micromedia	30503, 30539			Orbit	30872, 31643			
Logik		30713, 30884, 32594		Micromedia	30503, 30539			Orion	30695, 30713, 31233			
Logitech		32639		Micromedia	30503, 30539			Oritron	30651			
Lumatron		30741, 30695, 30713		Micromedia	30503, 30539			Ormond	30713			
Lunatron		30741		Micromedia	30503, 30539			Otic	31383			
Luxman		30573		Micromedia	30503, 30539			<b>P</b> Pacific	30831, 30790, 30713			
Luxor		30717, 30713, 30884		Micromedia	30503, 30539			Packard Bell	30831			
<b>M</b>		Magnasonic	30651		Micromedia	30503, 30539			Palladium	30695, 30713		
				Micromedia	30503, 30539							

AVR	CBL/SAT group	TV group	VCR/PVR group	BD/DVD group	Audio group
Palsonic	30672	Radiotone	30713	SEG	30713, 30872, 30884
Panasonic	30503, 30490, 31579, 31641, 31762, 32523, 32710, 32859, 33641, 33944, 33949	RCA	30522, 30571, 30717, 30790, 30822, 31769, 32213, 32587, 32592, 32594	Semp	30503
Panda	30717, 31107	RE-BL	32555	Shanghai	30672
Pelican Accessories	30533	REC	30490	Sharp	30630, 30675, 30713, 32250, 32479, 32652, 33313, 33314
Philco	30790, 30675	Recco	30698	Sherwood	30717, 30741, 30770, 31043
Philips	30503, 30539, 30646, 30675, 30713, 31267, 31340, 31354, 31506, 32056, 32084, 32334, 32434, 32789, 32791	Red	32213	Shinco	30717
Pioneer	30571, 30142, 30631, 31531, 31571, 32442, 32854	Red Star	30770, 31107	Shinsonic	30533
Play It	31643	Richmond	31233	Siemssen	31382
Polaroid	31061	Roadstar	30672, 30730, 30713	Sigmatek	32139
Polk Audio	30539	Ronin	30872	Silva Schneider	30741, 30831
Portland	30770	Rotel	30623	SilverCrest	32173
Powerpoint	30872	Rowa	30717, 30872	Sistemas	30672
Presidian	30675, 31738	Saba	30651, 30551, 31643, 32173	Skantic	30539, 30713
Prinz	30831	Saivod	30831	Skymaster	30730
Prism	30831	Salora	30741	SM Electronic	30730
PrivateLabel	32616	Sampo	30698	Smart	30713
Pro Vision	30730, 31107	Samsung	30490, 30573, 30744, 33195, 32951, 32942, 32843, 32556, 32489, 32329, 32107, 32069, 31635, 31470, 31075, 31044, 30820, 30199	Sogo	30672
Proceed	30672	Sansui	30695, 32082	Sonashi	30831
Proline	30672, 30651, 31643, 31738, 32082, 32616	Sanyo	30695, 30713	Soniq	30831
Proscan	30522	ScanMagic	30730	Sontech	31383
Proson	30713	Schaub Lorenz	30770, 31643, 32173	Sony	30533, 31533, 30864, 30772, 31033, 31070, 31431, 31516, 31536, 31633, 32132, 32178, 32180, 32504, 33519, 33939
Prosonic	32082, 32187	Schneider	30539, 30646, 30651, 30831, 30790, 30713	Sound Color	31233
Pye	30539, 30646	Schönteck	30713	Soundwave	30713
Q QONIX	30790	Scott	30672, 30651, 31233, 31383, 32173	Spectra	30872
Qwestar	30651	Seeltech	31643	SR Standard	30651, 30831
R Radionette	30741			Strato	31382
				Strong	30713
				Sunkai	30770

AVR	CBL/SAT group	TV group	VCR/PVR group	BD/DVD group	Audio group
Sunstech	30831, 32139	Thomson	30522, 30551, 30831	Wilson	30831, 31233
Superior	31643, 32173	Thule Audio	30551	Windsor	30713
Supersonic	33946	Tokai	30790, 30698, 31233	Windy Sam	30573
Supratech	32139	Tokaido	30698	Woxter	32139
SVA	30672, 30717		30503, 30695, 31154, 31510, 31769, 32006, 32277, 32551, 32705, 33157	<b>X</b> X-View	31233
Swisstec	32187	Toshiba		Xbox	30522
Sylvania	30630, 30675		TRANS- continents	Xenius	30790
Symphonic	30675		30831, 30872, 31233	Xiron	31383
Sytech	30831, 32139		Transonic	XMS	30770
<b>T</b> Tandberg	30713		Trent	<b>Y</b> Yamada	30872, 32139
Targa	30741		Trevi	Yamaha	30490, 30539, 30646, 30545, 30817, 31354, 32298, 32558
Tatung	30770		TVE	Yamakawa	30872
TBoston	32139	<b>U</b> UMC	30713	YBA	30872
Tchibo	30741		UMC	Yukai	30730
TCL	32587		United	<b>Z</b> Zenith	30503, 30741
TCM	30741, 30790		Universum		
Teac	30571, 30717, 30741, 30790, 30675, 31383, 32139		Urban Concepts		
Technica	30713, 30884		Venturer		
Technics	30490		Vestel		
Technika	30770, 30831, 31383, 32187		Viore		
Technisson	30672		Vizio		
Technosonic	30730		Voxson		
TechnoStar	31643		Vtrek		
Techwood	30713		Waitec		
TELE System	32173		Walkvision		
Telefunken	30551, 30790		Waltham		
Teletech	30713, 30884		WB Electronics		
Tensai	30651, 30770		Welkin		
Tevion	30651, 31382		Wellington		
Theta Digital	30571		Weltstar		
			Wharfedale		

### Blu-ray Disc

<b>D</b> Denon	32258, 32748, 33698, 32661
<b>E</b> Elite	32854
<b>F</b> Funai	30675
<b>H</b> Harman/Kardon	32927
<b>I</b> Insignia	30675, 32428, 32596
Integra	32147
<b>J</b> JVC	32365, 32855
<b>L</b> Lexicon	32545
LG	30741, 31602
<b>M</b> Magnavox	30675
Marantz	32534, 32414
Memorex	32331
Mitsubishi	33133

## AVR

## CBL/SAT group

## TV group

## VCR/PVR group

## BD/DVD group

## Audio group

<b>O</b>	Ölevia	32331
	Onkyo	32147, 32562
	Oppo	32545
<b>P</b>	Panasonic	31641, 32523, 32710, 32859, 33641, 33944, 33949
	Philips	32084, 32434, 32789
	Pioneer	30142, 32442, 32854
<b>S</b>	Samsung	30199, 32951, 33195
	Sharp	32250, 32479, 32652, 33313, 33314
	Sony	31516, 32178, 32180, 32504, 33519, 33939
	Sylvania	30675
<b>T</b>	Toshiba	32551, 32705, 33157
<b>V</b>	Viore	32553
	Vizio	32563
<b>Y</b>	Yamaha	32298

## DVD-R

<b>A</b>	Accurian	30675
	Aristona	30646
<b>D</b>	Denon	30490
	DigitalMax	31738
<b>E</b>	Emerson	30675
<b>F</b>	Funai	30675
<b>G</b>	Go Video	30741
	GPX	30741
<b>H</b>	Humax	30646
<b>I</b>	Irradio	30646
<b>J</b>	JVC	31164
<b>L</b>	LG	30741

	LiteOn	31738
	Loewe	30741
<b>M</b>	Magnavox	30646, 30675, 31506
	Medion	30741
	Mitsubishi	33133
<b>P</b>	Panasonic	30490, 31579, 32523, 32710, 32859, 33944, 33949
	Philips	30646, 31340, 31506
	Pioneer	30631
	Presidian	31738
	Proline	31738
	Pye	30646
<b>R</b>	RCA	30522
<b>S</b>	Samsung	30490, 31470, 31635, 32107, 32489, 32942
	Schneider	30646
	Sharp	30630, 30675, 32479, 33313, 33314
	Sony	31033, 31070, 31431, 31516, 31536, 31633, 32132, 32178, 32180, 33519, 33939
	Sylvania	30675
<b>T</b>	Targa	30741
	Thomson	30551
	Toshiba	31510, 32277, 32551
<b>Y</b>	Yamaha	30646
<b>Z</b>	Zenith	30741

## HD-DVD

<b>I</b>	Integra	31769
<b>L</b>	LG	30741
<b>O</b>	Onkyo	31769

<b>R</b>	RCA	31769
<b>T</b>	Toshiba	31769

## TV/DVD Combination

<b>A</b>	Acoustic Solutions	32082
	Akai	30695
	Akura	31383
	Alba	30695, 30884
	Audiosonic	31383
<b>B</b>	Black Diamond	30713, 30884
	Blue Sky	30713, 30884
	Broksonic	30695
	Bush	30713, 30884, 31383
<b>C</b>	Centrum	30713
	Citizen	30695
	Crown	30713
<b>D</b>	Dual	30713, 30884
<b>E</b>	Elfunk	30713, 30884
	Emerson	30675
<b>F</b>	Ferguson	30695, 30713, 30884
<b>G</b>	Goodmans	30713, 30884, 31383
	Grandin	30713
	Grundig	30539, 30695
<b>H</b>	Hikona	31383
	Hitachi	30713, 30884
<b>L</b>	Lenco	31383
	Logik	30713, 30884
	Luxor	30713, 30884
<b>M</b>	Matsui	30713, 30884
	Memory	31383



	Mx Onda	31383
<b>O</b>	Orion	30695
	Otic	31383
<b>P</b>	Philips	30539
	Proline	32082
	Prosonic	32082
<b>S</b>	Sansui	30695, 32082
	Scott	31383
	SEG	30713, 30884
	Sontech	31383
	Supersonic	33946
	Sylvania	30630, 30675
<b>T</b>	Teac	31383
	Technica	30713, 30884
	Technika	31383
	Teletech	30713, 30884
	Thomson	30551
	Toshiba	30695
<b>U</b>	United	30713, 30884, 31383
	Universum	30713
<b>V</b>	Venturer	32082
	Vestel	30884
<b>W</b>	Weltstar	30713
	Wharfedale	31383
<b>X</b>	Xiron	31383

### TV/VCR/DVD Combination

<b>F</b>	Ferguson	30695
<b>M</b>	Matsui	30695
<b>S</b>	Sharp	30630

## Audio group

### CD

<b>A</b>	Acoustic Research	40420
	Advantage	40032
	AH!	40157
	Aiwa	40157
	Arcam	41985, 40157
	Atoll Electronique	40157
	Audio Research	40157
	Audiolab	40157
	Audiomeca	40157
	Audioton	40157
	AVI	40157
<b>B</b>	Balanced Audio Technology	40157
	Burmester	40420
<b>C</b>	Cairn	40157
	California Audio Labs	40029, 40303
	Cambridge	40157
	Cambridge Audio	40157
	Carver	40157
	CCE	40157
	CDC	40420
	CEC	40420
	Cyrus	40157
<b>D</b>	Denon	40626, 40003, 42867, 42868
	DKK	40000
	DMX Electronics	40157

	Dual	40003
	Dynaco	40157
<b>G</b>	Garrard	40420
	Genexxa	40000, 40032
	Goldmund	40157
	Grundig	40157
<b>H</b>	Harman/Kardon	40157, 40173
	Hitachi	40032
<b>I</b>	Inkel	40180
	Integra	40101
<b>J</b>	JVC	40072
<b>K</b>	Kenwood	40626, 40157, 40028, 40036
	Krell	40157
<b>L</b>	Linn	40157
	Loewe	40157
	Lyngdorf	42766
<b>M</b>	Magnavox	40157
	Marantz	41985, 40626, 40029, 40157, 40180
	Matsui	40157
	MCS	40029
	Memorex	40032, 40180
	Meridian	40157
	Micromega	40157
	Miro	40000
	Mission	40157
	MTC	40420
	Myryad	40157
<b>N</b>	NAD	40000

	Naim	40157
	NSM	40157
<b>O</b>	Onkyo	40101
	Optimus	40000, 40032, 40420
<b>P</b>	Panasonic	40029, 40303, 40752
	Parasound	40420
	Philips	40626, 40157
	Pioneer	40032, 40101
	Polk Audio	40157
	Primare	40157
	Proceed	40420
	Proton	40157
<b>Q</b>	QED	40157
	Quad	40157
	Quasar	40029
<b>R</b>	Radiola	40157
	RCA	40032, 40420
	Realistic	40180, 40420
	Restek	40157
	Revox	40157
	Roksan	40420
	Rotel	40157, 40420
	Royal	40420
<b>S</b>	SAE	40157
	Sansui	40157
	SAST	40157
	Sharp	40180
	Sherwood	40180

Siemens 40157

Silsonic 40036

Simaudio 40157

Sonic Frontiers 40157

Sony 40490, 40000, 41364, 40185

Sylvania 40157

**T** TAG McLaren 40157

Tandy 40032

Tangent 43304

Tascam 40420

Teac 40180, 40420

Technics 40029, 40303

Thorens 40157

Thule Audio 40157

Tokai 40420

Traxdata 40626

**U** Universum 40157**V** Victor 40072**W** Wards 40000, 40032, 40157**Y** Yamaha 40490, 40032, 40036**Z** Zonda 40157**CD-R****D** Denon 40626, 42868**J** JVC 40072**K** Kenwood 40626**M** Marantz 40626**P** Philips 40626**R** RCA 40420**S** Sony 40000, 41364**T** Teac 40420